

Digital HD Video Camera Recorder

HXR-NX5E/NX5P/NX5M

Operating Guide

Before operating the unit, please read this manual thoroughly, and retain it for future reference.















Read this first

Before operating this unit, please read this manual thoroughly, and retain it for future reference.

To handle the recorded images on your computer

Refer to "Help" on the supplied CD-ROM "Content Management Utility."

Notes on use

Types of memory cards you can use in your camcorder

You can use "Memory Stick PRO Duo" media, "Memory Stick PRO-HG Duo" media, SD memory cards, and SDHC memory cards in your camcorder. You cannot use a MultiMedia Card.

- "Memory Stick PRO Duo" media and "Memory Stick PRO-HG Duo" media are both called "Memory Stick PRO Duo" media in this manual.
- See page 101 for the recordable time of memory cards.
- Up to 32 GB of memory cards are confirmed to be used with your camcorder.

Types of "Memory Stick PRO Duo" media you can use in your camcorder

- It is recommended to use "Memory Stick PRO Duo" media of 1 GB or larger marked with:
 - MEMORY STICK PRO DUD ("Memory Stick PRO Duo" media)*
 - MEMORY STICK PRO-HG DUO ("Memory Stick PRO-HG Duo" media)
- * Marked with Mark2 or not, either can be used.

"Memory Stick PRO Duo" media/"Memory Stick PRO-HG Duo" media (This size can be used with your camcorder.)



"Memory Stick" media (You cannot use it in your camcorder.)



4 Notes

- "Memory Stick PRO Duo" media can be used only with "Memory Stick PRO" media compatible equipment.
- Do not attach a label or the like on "Memory Stick PRO Duo" media or a "Memory Stick Duo" media adaptor.
- When using a "Memory Stick PRO Duo" media with "Memory Stick" media compatible equipment, insert the "Memory Stick PRO Duo" media into the "Memory Stick Duo" media adaptor.

Using the camcorder

• Do not hold the camcorder by the following part.



Lens hood



LCD panel



Internal microphone



Microphone or Microphone holder




Viewfinder

4 Notes

- · The camcorder is not dustproof, dripproof or See "About handling of your camcorder"
 - (p. 109).
- · Connect cables to your camcorder with their terminals placed the correct way. Squeezing the terminals into your camcorder's jacks may damage them or results in a malfunction of your camcorder
- . HXR-NX5E/NX5P: Even if the camcorder is turned off, the GPS function is working as long as the GPS switch is set to ON. Make sure that the GPS switch is set to OFF during take off and landing of an airplane.

About menu items, LCD panel, viewfinder, and lens

- A menu item that is graved out is not available under the current recording or playback conditions.
- The LCD screen and the viewfinder are manufactured using extremely highprecision technology, so over 99.99% of the pixels are operational for effective use. However, there may be some tiny black points and/or bright points (white, red, blue, or green in color) that appear constantly on the LCD screen and/or the viewfinder. These points are normal results of the manufacturing process and do not affect the recording in any way.



White, red, blue or green point

Do not expose your camcorder's viewfinder. Iens. or LCD screen to the sun or strong light source for extended periods.

• Intense light sources, especially the sun will converge on the viewfinder or lens and damage the internal parts of your camcorder. Avoid sunlight or other strong light sources when storing your camcorder. Protect this device by always closing the lens cover or by placing it in its bag when not in use.

About temperature of your camcorder and battery pack

 Your camcorder has a protective function that disables recording or playback if the temperature of your camcorder or battery pack is beyond the safely operable range. In this case, a message appears on the LCD screen or in the viewfinder (p. 99).

On recording

- · In order to stabilize memory card operation, it is recommended that you format the memory card when you use it with your camcorder for the first time. All data recorded on the memory card will be erased by formatting, and can not be recovered. Save important data on the memory card on other media such as a computer, before formatting the memory card.
- · Before starting to record, test the recording function to make sure the picture and sound are recorded without any problems.
- Compensation for the loss of the content of recordings or the loss of recording opportunities cannot be provided, even if recording or playback is not possible due to a malfunction of the camcorder, storage media, etc., or even if images or sounds are distorted due to the limits of the capabilities of the camcorder.
- TV color systems differ depending on the countries/regions. To view your

Read this first (Continued)

recordings on a TV, you need a PAL system-based TV.

- Television programs, films, video tapes, and other materials may be copyrighted.
 Unauthorized recording of such materials may be contrary to the copyright laws.
- Because of the way that the image device (CMOS sensor) reads out image signals, the following phenomena may occur.
 - The subjects passing by the frame rapidly might appear crooked depending on the recording conditions. (This phenomenon may be notable in displays having high motion resolution.)
 - Horizontal lines appear on the screen during recording under fluorescent lights. The phenomena can be reduced by adjusting the shutter speed (p. 29).
 - Images on the screen look horizontally divided when a subject is lighted with a flash.
 The phenomena can be reduced by using a slower shutter speed.

On playing back movies

- Your camcorder is compatible with MPEG-4 AVC/H.264 High Profile for high definition image quality (HD) recording. Therefore, you cannot play back images recorded with high definition image quality (HD) on your camcorder with the following devices;
 - Other AVCHD format compatible devices which are not compatible with High Profile
 - Devices which are not compatible with the AVCHD format
- Movies made using this camcorder may not play back normally on devices other than this camcorder. Also, movies recorded on other devices may not play back properly on this camcorder.

Discs recorded with high definition image quality (HD)

This camcorder captures high definition footage in the AVCHD format. DVD media containing AVCHD footage should not be used with DVD based players or recorders, as the DVD player/recorder may fail to

eject the media and may erase its contents without warning.

Save all your recorded image data

To prevent your image data from being lost, save all your recorded images on external media periodically. It is recommended that you save the image data on a computer using the supplied application software.

Format the recording media using [MEDIA FORMAT] if images are not recorded or played back properly

If you continue recording and deleting images on recording media for a long time, the files on that recording media may be fragmented. As a result, you may not be able to record and save images properly. If this happens, save images on a separate recordable media, such as a disc or computer, then format the recording media (p. 65).

Note on disposal/transfer

Even if you delete all data or format the recording media on your camcorder or computer, you may not delete data from the recording media completely. When you transfer the recording media or your camcorder, it is recommended that you delete the data completely using commercially available data deletion software to prevent the recovery of your data. Also, when you dispose of the recording media, it is recommended that you destroy the actual body of the recording media.

About the operation of the camcorder

You can operate the camcorder using the SEL/PUSH EXEC dial/◆/◆ buttons (p. 17), ★/◆/◆/EXEC buttons (p. 67), and the touch panel. However, you cannot use the touch panel to make some settings such as the MENU items

About this manual

- Memory cards and a flash memory unit are both referred to as recording media in this manual.
- The images of the LCD screen and the viewfinder used in this manual for illustration purposes are captured using a digital still camera, and therefore may appear different.
- The on-screen displays in each local language are used for illustrating the operating procedures. Change the screen language before using your camcorder if necessary (p. 18).
- Design and specifications of recording media and other accessories are subject to change without notice.
- Illustrations of camcorders in this manual show the HXR-NX5E unless otherwise specified.
- Illustrations of battery packs in this manual show the NP-F770 unless otherwise specified.

Table of Contents

first	2
ed	
necking supplied itemstaching the supplied microphone and the lens hood with	lens
narging the battery pack Irning the power on and holding your camcorder properly Jjusting the LCD panel and viewfinder Etting the date and time Changing the language setting serting a memory card/Attaching a flash memory unit	12 /14 15 17
layback	
Changing the setting of the record button/handle record button Selecting high definition image quality (HD) or standard definition image quality (SD) Selecting the recording format the settings of your camcorder recordings Adjusting the zoom Adjusting the focus manually Adjusting the image brightness Adjusting to natural color (White balance) Customizing the picture quality (Picture profile) Acquiring location information (HXR-NX5E/NX5P) Recording with the SMOOTH SLOW REC function Setting time data	23 ion 24 25 26 27 28 30 32 39 41 42 43
the functions to the ASSIGN buttons Viewing still images	47
/checking the settings in your camcorder	51 51 51
	necking supplied items

Editing Operating the MODE menu57 Protecting recorded images (Protect)58 Using the Playlist of movies59 Capturing still images from a movie60 Dividing a movie61 Deleting movies and still images62 Dubbing movies/copying still images63 Formatting the recording media65 Preventing data on recording media from being recovered65 Repairing the image database file66 Using the Menu Operating the menu67 Menu items69 Time (CAMERA SET) menu71 Settings to adjust your camcorder to the recording conditions (GAIN SET/ BACK LIGHT/STEADYSHOT, etc.) (REC/OUT SET) menu77 Recording settings, input and output settings (REC SET/VIDEO OUT) 🎤 (AUDIO SET) menu78 Settings for the audio recording (AUDIO FORMAT/XLR SET, etc.) (DISPLAY SET) menu81 Display settings of the display and the viewfinder (MARKER/VF BACKLIGHT/ DISPLAY OUTPUT, etc.) 0500 (TC/UB SET) menu85 (TC PRESET/UB PRESET, etc.)

Connecting with a Computer

Saving images with a computer88

(OTHERS) menu86 Settings while recording or other basic settings (AREA SET/BEEP, etc.)

Table of Contents (Continued)

Troubleshooting	
Troubleshooting	
Additional Information	
Recording time of movies Using your camcorder abroad File/folder structure on the memory card and the flash memory unit . Maintenance and precautions About the AVCHD format About GPS (HXR-NX5E/NX5P) About the "Memory Stick" media About the "InfoLITHIUM" battery pack About charging the battery pack About x.v.Color About handling of your camcorder Specifications	103 104 105 105 105 106 107 108 109
Quick Reference	
Identifying parts and controls	122

Step 1: Checking supplied items

Make sure that you have following items supplied with your camcorder.

The number in the parentheses indicates the number of that item supplied.

 Memory cards are not included. See pages 2 and 106 for types of memory cards that you can use on your camcorder.

AC Adaptor/Charger (AC-VL1) (1) (p. 12)



Power cord (mains lead) (1) (p. 12)




Wireless Remote Commander (RMT-845) (1) (p. 121)



A button-type lithium battery is already installed.

Component video cable (1) (p. 54)



A/V connecting cable (1) (p. 54)



USB cable (1) (p. 88)



Large eyecup (1) (p. 16)




Rechargeable battery pack (NP-F570) (1) (p. 12, 107)



Lens hood with lens cover (1) (p. 10) This lens hood is pre-mounted.



Wind Screen (1), Microphone (ECM-XM1) (1) (p. 10)



Accessory shoe kit (Accessory shoe (1), Accessory shoe plate (1), screws (4)) (p. 116)



Connecting cord (DK-415) (1) (p. 13)

CD-ROM "Content Management Utility" (1)


CD-ROM "Manuals for Digital HD Video Camera Recorder" (1)

Operating Guide (2)

Step 2: Attaching the supplied microphone and the lens hood with lens cover


Attaching the supplied microphone

When you use the supplied microphone (ECM-XM1) for recording sound, do the following steps.




- 1 Attach the wind screen B to the supplied microphone A.
- 2 Place the microphone A in the microphone holder C with the model name facing upward, close the cover, and shut the clamp.
- 3 Connect the plug of the microphone to the INPUT1 jack D.

4 Put the microphone cable into the cable holder $\boxed{\mathbb{E}}$.



Hook the cable in the outer cable holder.

Attaching the lens hood with lens cover



PUSH (lens hood release) button

Align the marks on the lens hood to those on the camcorder, and turn the lens hood in the direction of the arrow ② until it is locked.

To remove the lens hood with lens cover


Turn the lens hood in the opposite direction to the arrow ② in the illustration while pressing the PUSH (lens hood release) button.

Ϋ́ Tips

 If you attach or remove a 72mm (2 7/8 in.) PL filter or MC protector, remove the lens hood with lens cover.

To open or close the shutter of the lens hood with lens cover

Move the lens cover lever to OPEN to open the lens cover, and move the lever to CLOSE to close the lens cover.




Step 3: Charging the battery pack

You can charge the "InfoLITHIUM" battery pack (L series) with the supplied AC Adaptor/Charger.

4 Notes

• You cannot use batteries other than the "InfoLITHIUM" battery pack (L series) (p. 107).



- 1 Set the mode switch to CHARGE.
- 2 Connect the power cord (mains lead) to the AC Adaptor/Charger.
- 3 Connect the power cord (mains lead) to the wall outlet (wall socket).
- 4 Place the battery pack in the slot of the AC Adaptor/Charger, press it down, and slide it in the direction of the arrow as illustrated.


The charge lamp turns on and charging starts.

After charging the battery

The charge lamp turns off (normal charge). If you continue charging more 1 hour after the charge lamp turns off, you can use the battery a little longer (full charge). Remove the battery pack from the AC Adaptor/Charger when the charge is completed.

To attach the battery pack

Press the battery pack against the back of your camcorder and slide it down.



Ϋ́ Tips

• You can check the remaining battery life with the status check function (p. 52).

To remove the battery pack

Slide the POWER switch to OFF. Push the BATT RELEASE (battery release) button and remove the battery pack.



BATT RELEASE (battery release) button

To store the battery pack

If the battery pack is not in use for a while, run down the battery and store it. See page 108 for details on storage of the battery pack.

Charging time

Approximate time (min.) required when you charge a fully discharged battery pack.

Battery pack	Normal charge time	Fully charge time
NP-F570	140	200
NP-F770	250	310
NP-F970	365	425

4 Notes


- · The supplied battery pack is NP-F570.
- · You cannot use the NP-F330 battery pack with your camcorder.

On the battery pack

- · Before changing the battery pack, slide the POWER switch to OFF.
- The Battery Info (p. 52) will not be correctly displayed under the following conditions.
 - The battery pack is not attached correctly.
 - The battery pack is damaged.
 - The battery pack is worn-out.

Using an outside power source

You can use the AC Adaptor/Charger to obtain AC power.



- 1 Connect the power cord (mains lead) to the AC Adaptor/Charger.
- 2 Connect the power cord (mains lead) to the wall outlet (wall socket).
- 3 Connect the connecting cord (DK-415) to the AC Adaptor/Charger.
- 4 Set the mode switch of the AC Adaptor/ Charger to VCR/CAMERA.
- 5 Press the connecting part of the connecting cord (DK-415) against the back of your camcorder in the battery slot and slide it down

On the AC Adaptor/Charger

- · Use the nearby wall outlet when using the AC Adaptor/Charger. Disconnect the AC Adaptor/ Charger from the wall outlet (wall socket) immediately if any malfunction occurs while using your camcorder.
- · Do not use the AC Adaptor/Charger placed in a narrow space, such as between a wall and
- Do not short-circuit the DC plug of the AC Adaptor/Charger or battery terminal with any metallic objects. This may cause a malfunction.


Step 3: Charging the battery pack (Continued)

 Even if your camcorder is turned off, AC power (house current) is still supplied to it while connected to the wall outlet (wall socket) via the AC Adaptor/Charger.

Step 4: Turning the power on and holding your camcorder properly

To record or play back, set the POWER switch to ON.

When you use your camcorder for the first time, the [CLOCK SET] screen appears (p. 17).



1 Slide the POWER switch to ON while you press the green button.




Press and hold the green button.


Wotes

 The current date and time appear on the LCD screen for a few seconds when you turn on your camcorder after you set the date and time with [CLOCK SET], p. 17.

2 Hold the camcorder properly.



3 Ensure a good grip, then fasten the grip belt.



To turn off the power

Slide the POWER switch to OFF.


4 Notes

· If warning messages appear on the screen, follow the instructions

Step 5: Adjusting the LCD panel and viewfinder

LCD panel

Open the LCD panel 180 degrees (1), then rotate it to the best angle to record or play back (2).



DISPLAY button

🌣 Tips

· Images are displayed as mirror images on the LCD screen, but are recorded as normal images.

To turn off the LCD backlight to make the battery last longer


Press and hold the DISPLAY button for a few seconds until FOFF appears. This setting is practical when you use your camcorder in bright conditions or when you want to save battery power. The recorded picture will not be affected by the setting. To turn on the LCD backlight, press and hold the DISPLAY button for a few seconds until FOFF disappears. Also, you can turn on the LCD backlight by turning on/off the camcorder.

Ÿ Tips

· You can adjust the brightness of the LCD screen from [LCD BRIGHT] (p. 83).

Step 5: Adjusting the LCD panel and viewfinder (Continued)

Viewfinder lens adjustment lever Move it until the picture becomes clear.



Notes

 You may see primary colors shimmering in the viewfinder when you move your line of sight. This is not a malfunction. The shimmering colors will not be recorded on the recording media.

🍟 Tips

- You can adjust the brightness of the viewfinder backlight from [VF BACKLIGHT] (p. 83).
- To display images both on the LCD display and in the viewfinder, set [VF POWERMODE] to [ON] (p. 84).
- To display images in black and white in the viewfinder, set [VF COLOR] to [OFF] (p. 84).

When the picture in the viewfinder is hard to see

If you cannot see the picture in the viewfinder clearly under bright circumstances, use the supplied large eyecup. To attach the large eyecup, stretch it slightly and align it with the eyecup groove in the viewfinder. You can attach the large eyecup facing either the right or left side.

Wotes


• Do not remove the pre-attached eyecup.

Step 6: Setting the date and time

Set the date and time when using your camcorder for the first time. If you do not set the date and time, [CLOCK SET] screen appears every time you turn on your camcorder.

aqiT 👸

• If you do not use your camcorder for about 3 months, the built-in rechargeable battery gets discharged and the date and time settings may be cleared from the memory. In that case, charge the rechargeable battery and then set the date and time again (p. 111).




Skip to step 4 when you set the clock for the first time

Press the MENU button.

2 Select (OTHERS) by turning the SEL/PUSH EXEC dial, then press the dial.



 $oldsymbol{3}$ Select [CLOCK SET] by turning the SEL/PUSH EXEC dial, then press the dial.



4 Select your area by turning the SEL/PUSH EXEC dial, then press the dial.



5 Set [SUMMERTIME], [Y] (year), [M] (month), [D] (day), hour and minute, by turning the SEL/PUSH EXEC dial, then press the dial.

Step 6: Setting the date and time (Continued)



The clock starts.

- Set [SUMMERTIME] to [ON] to move the time forward 1 hour.
- You can set any year up to the year 2037.

🍟 Tips

 The date and time are automatically recorded on the selected recording media, and can be displayed during playback (DATA CODE button, p. 51).


Changing the language setting

You can change the on-screen displays to show messages in a specified language. Press the MENU button and select (OTHERS) with the SEL/PUSH EXEC dial. Select the screen language in [LANGUAGE] (p. 86).

Step 7: Inserting a memory card/Attaching a flash memory unit


Memory card

Open the cover in the direction of the arrow.



2 Orient the memory card's notched corner as shown in the illustration, and insert into the memory card slot until it clicks.

> Memory card slot A and its access lamp



Insert with the notched corner first, and facing down.

6) Notes

· If you insert a memory card into the slot in the wrong direction, the memory card, the memory card slot, or image data may be damaged.

· When you insert a new memory card in standby mode, the [Create a new Image Database File.] screen appears. Follow the screen indication, and touch [YES].

To eject the memory card


Lightly push the memory card once.

4 Notes

- · When the access lamp is lit or flashing in red, your camcorder is reading/writing data. Do not shake or knock your camcorder, turn the power off, eject the memory card, or remove the battery pack. Otherwise, image data may be damaged.
- · If [Failed to create a new Image Database File. It may be possible that there is not enough free space.] appears in step **2**, format the memory card (p. 65).
- · When inserting or ejecting the memory card, be careful to prevent the memory card from popping out and dropping.

Selecting the memory card slot to be used for recording

Press the A or B button of the memory card slot where the memory card you want to record on is inserted. The lamp of the selected slot lights up in green.



Memory card slot B button

Step 7: Inserting a memory card/Attaching a flash memory unit (Continued)

4 Notes

- You can only select a slot that already has a memory card inserted.
- While movies are being recorded on the memory card, you cannot switch the slot even if you press the memory card slot A/B buttons.


Ϋ́ Tips

- When only one slot has a memory card inserted, the slot that has the memory card is selected automatically.
- If the memory card is fully recorded during recording, the camcorder continues recording automatically on the memory card inserted in the other slot (Relay recording, p. 22).


Flash memory unit

You can attach a flash memory unit HXR-FMU128 (sold separately) to your camcorder for recording movies.

1 While sliding the RELEASE lever in the direction of the arrow, remove the flash memory unit jack cover.



2 Align the mark on the camcorder and that on the flash memory unit, and slide the flash memory unit in the direction of the arrow.



3 When [EXT media has been attached. It is necessary to reboot. Execute?] appears on the screen, touch [YES].

(3 Notes


• If you touch [NO] in step **3**, turn on your camcorder again. You will be able to record in the flash memory unit.

To remove the flash memory unit

Turn off your camcorder, and while sliding the RELEASE lever in the direction of arrow, remove the flash memory unit.

When you do not use an flash memory unit, leave the flash memory unit jack cover attached.

Recording




Your camcorder records movies on memory cards or a flash memory unit. Do the following steps to record movies.

• This camcorder can record movies in either high definition image quality (HD) or standard definition image quality (SD). The factory setting is high definition image quality (HD) ([HD]/HSDHSET], p. 24).


Notes

- · When the access lamp is lit or flashing in red, your camcorder is writing data on recording media. Do not shake or knock your camcorder, or remove the battery pack or the AC Adaptor/Charger.
- · See page 101 on the recording time of movies.
- · Your camcorder can record movies for about 13 hours continuously.
- If a movie file exceeds 2 GB during recording, the camcorder divides the file and create a new file automatically.
- The menu settings, the PICTURE PROFILE settings, and the settings made by the AUTO/MANUAL switch are stored in your camcorder when you turn the POWER switch to OFF. The access lamp lights up while the settings are being stored. If you remove the battery pack or the AC Adaptor/Charger before turning off the power, the settings may return to the default settings.


Open the shutter of the lens hood.



2 Slide the POWER switch to ON while pressing the green button.



3 Press the record button or the handle record button.



The recording lamp lights up during recording.

To stop the movie recording, press the record button or the handle record button again.


🍟 Tips

- When recording in high definition image quality (HD), the aspect ratio is fixed to 16:9. When recording in standard definition image quality (SD), you can switch the aspect ratio to 4:3 ([SD]] WIDE REC], p. 77).
- You can change the screen display during recording (p. 51).
- Indicators displayed on the screen during recording are shown on page 122.
- $\bullet \ \ The \ recording \ lamp \ can \ be \ set \ to \ stay \ off \ ([REC\ LAMP[F]], \ [REC\ LAMP[R]], \ p.\ 86).$
- For low angle recording, the handle record button is convenient. Release the HOLD lever to enable the
 handle record button. It might be helpful if you set the LCD panel face up or close it after turning it face
 down, or lift the viewfinder up during the low angle recording.
- You can capture still images from the movies you recorded (p. 60).

To continue recording on the memory cards, one after another (Relay recording)

Insert memory cards each in both slots A and B, so the camcorder switches memory card A (or B) just before space on the other one runs out, and continues recording on the next memory card automatically.

Insert a recordable memory card.



4 Notes

- · Do not eject the memory card that is currently being used for recording. Replace only the memory card whose slot lamp is off.
- Even if you press the memory card slot button, A or B, while recording movies, you cannot switch the slot currently being used.
- When the remaining recording time of the memory card being used is less than 1 minute and the other slot has recordable memory card inserted, $[\underbrace{\exists A} \rightarrow \underbrace{\exists B}]$ or $[\underbrace{\exists B} \rightarrow \underbrace{\exists A}]$ appears on the camcorder screen. The indicator turns off when the memory card is switched.
- If you start recording on a memory card with the remaining recording time of less than 1 minute, the camcorder may not be able to relay-record. To relay-record without fail, make sure that the memory card has more than 1 minute when you start recording.
- Seamless playback of relay-recorded movies with this camcorder is not possible.
- · You can re-combine relay-recorded movies using the supplied application software (Windows only).

To record movies using both the memory card and the flash memory unit (Simultaneous recording)

You can record movies on both of these recording media simultaneously.

You can change the recording media using the record button and the handle record button with [REC BUTTON SET] (p. 23).

4 Notes

· You cannot record on the memory cards in slots A and B simultaneously.

Ÿ Tips

- · Relay recording works during simultaneous recording on different media.
- · If one of the recording media used becomes unable to continue recording during simultaneous recording, the other recording media continues recording without pause.

Changing the setting of the record button/handle record button

You can start and stop recording on different recording media at different timing by operating the record button and the handle record button.

In the default setting, movies are recorded on both the memory card and the flash memory unit at the same time when either record button is pressed.

Recording (Continued)

- REC BUTTON:[☐][☐EXT]
- HANDLE REC BUTTON:[☐][☐EXT]

To change the setting

Press MENU \rightarrow select \Longrightarrow (REC/OUT SET) \rightarrow [REC SET] \rightarrow [REC BUTTON SET] with the SEL/PUSH EXEC dial.

[REC BUTTON SET] setting	Button and recording media
REC BUTTON:[] [EXT] HANDLE REC BUTTON:[] [EXT]	Recording on both the memory card and the flash memory unit starts and stops at the same time when either record button is pressed.
REC BUTTON:[]] HANDLE REC BUTTON:[EXT]	Recording on the memory card starts and stops when the record button is pressed, and on the flash memory unit when the handle record button is pressed.
REC BUTTON:[EXT] HANDLE REC BUTTON:[]	Recording on the flash memory unit starts and stops when the record button is pressed, and on the memory card when the handle record button is pressed.

Selecting high definition image quality (HD) or standard definition image quality (SD)

You can set the recording image quality, high definition image quality (HD) or standard definition image quality (SD), separately for the memory card and the flash memory unit.

To change the setting

Press MENU \rightarrow select \Longrightarrow (REC/OUT SET) \rightarrow [REC SET] \rightarrow [\Longrightarrow SET] with the SEL/PUSH EXEC dial.

To record in high definition image quality (HD)

Select $[\underbrace{ : \text{HD:} }_{\text{EXT}} : \underbrace{\text{HD:} }_{\text{in}}]$ in $[\underbrace{\text{HD:} }_{\text{ISD:}} \text{SET}]$.

Images are recorded in high definition image quality (HD) on the memory card and the flash memory unit.

To record in standard definition image quality (SD)

Wotes

 You cannot record in standard definition image quality (SD) on both the memory card and the flash memory unit simultaneously.

Selecting the recording format

You can select the recording format (bit-rate, image size, frame rate, scanning system). In the default setting, [#ID# 1080/50i FX | #SD# 576/50i H□] is selected.

To change the setting

Press MENU \rightarrow select \Longrightarrow (REC/OUT SET) \rightarrow [REC SET] \rightarrow [REC FORMAT] with the SEL/PUSH EXEC dial

Setting value	Description
1080/50i <u>FX</u> 1SDI 576/50i <u>FQ</u>	Bit-rate FX: max. 24 Mbps FH: approx. 17 Mbps (average)
##D# 1080/50i <u>FH</u> #SD# 576/50i <u>FQ</u>	HQ: approx. 9 Mbps (average) LP: approx. 5 Mbps (average)
##D# 1080/50i #IQ #SD# 576/50i #IQ	• Image size FX: 1920×1080/1280×720 FH: 1920×1080/1280×720
##D# 1080/50i <u>LP</u> #\$D# 576/50i <u>HQ</u>	HQ: HD recording 1440×1080 SD recording 720×576 LP: 1440×1080
##D# 1080/25p <u>FX</u> #SD# 576/25p SCAN <u>HQ</u>	• Frame rate either 25 or 50
##D# 1080/25p <u>FH</u> #\$D# 576/25p SCAN <u>HQ</u>	Scanning system i: interlace p: progressive
#HD# 720/50p <u>FX</u> #SD# 576/50i <u>HQ</u>	pSCAN: Records images of progressive scanning system as interlace signal (50i).
##D# 720/50p <u>FH</u> #SD# 576/50i <u>FQ</u>	

Setting value

If you select [$\frac{1080}{50}$ $\frac{1080}{50}$ $\frac{1}{50}$], for example, movies are recorded with following format.

- HD: High definition image quality. SD is standard definition image quality.
- 1080: Effective scanning lines
- 50: Frame rate
- i: Scanning system
- FX: Recording mode

Notes


- The recording mode is fixed to FX or FH with the progressive scanning system.
- When the recording format is changed to or from the 720/50p, you will be prompted to reboot the camcorder. Select [YES]. Otherwise, you cannot switch the recording format.

Ÿ Tips

• When [: HD: | FXT: HD:] in [HD: / SD! SET] is selected, | SD! items are grayed out.

Changing the settings of your camcorder recordings


Adjusting the zoom



Using the power zoom lever

Move the power zoom lever \boxed{D} slightly for a slower zoom. Move it further for a faster zoom.

Wide view: (Wide angle)



Close view: (Telephoto)

🍟 Tips

- The minimum distance required between your camcorder and the subject for focus is about 1 cm (about 13/32 in.) for wide angle and about 80 cm (about 2 5/8 feet) for telephoto.
- The focus may not be adjusted at certain zoom positions if the subject is within 80 cm (about 2 5/8 feet) from your camcorder.
- When you set [FOCUS MACRO] to [OFF], you cannot focus on a subject within 80 cm (about 2 5/8 feet) regardless of the zoom position (p. 74).
- Be sure to keep your finger on the power zoom lever D. If you move your finger off the power zoom lever D, the operation sound of the power zoom lever D may also be recorded.
- You can increase the zoom speed of the power zoom lever $\boxed{\textbf{D}}$ or the handle zoom $\boxed{\textbf{A}}$ ([SPEED ZOOM], p. 74).

Using the handle zoom

① Set the handle zoom switch **B** to VAR or FIX.

Ϋ́ Tips

- When you set the handle zoom switch B to VAR, you can zoom in or out at variable speed.
- When you set the handle zoom switch **B** to FIX, you can zoom in or out at fixed speed set in [HANDLE ZOOM] (p. 74).
- 2 Press the handle zoom lever A to zoom in or out.

4 Notes

- You cannot use the handle zoom lever A when the handle zoom switch B is set to OFF.
- You cannot change the zoom speed of the power zoom lever D with the handle zoom switch B.


Using the zoom ring

You can zoom at the desired speed by turning the zoom ring $\boxed{\mathbf{C}}$. Fine adjustment is also possible.

O Notes

 Turn the zoom ring at a moderate speed. If you turn it too fast, the zoom speed may lag behind the zoom ring rotation speed, or the operation sound of the zoom may also be recorded.


Adjusting the focus manually



You can adjust the focus manually for different recording conditions.

Use this function in the following cases.

- To record a subject behind a window covered with raindrops.
- To record horizontal stripes.
- To record a subject with little contrast between the subject and its background.
- When you want to focus on a subject in the background.



- To record a stationary subject using a tripod.

1 During recording or standby, set the FOCUS switch B to MAN.

appears.

2 Rotate the focus ring A and adjust the focus.

changes to when the focus cannot be adjusted any farther. changes to \triangle when the focus cannot be adjusted any closer.

aqiT 🌣

For focusing manually

- · It is easier to focus on the subject when you use the zoom function. Move the power zoom lever towards T (telephoto) to adjust the focus, and then, towards W (wide angle) to adjust the zoom for recording.
- · When you want to record a close-up image of a subject, move the power zoom lever towards W (wide angle) to fully magnify the image, then adjust the focus.

To restore automatic adjustment

Set the FOCUS switch **B** to AUTO. € disappears and the automatic focus adjustment is restored.

Using automatic focus temporarily (Push auto focus)

Record the subject while pressing and holding the PUSH AUTO button C. If you release the button, the setting returns to manual focusing.

Use this function to shift the focus on one subject to another. The scenes will shift smoothly.

Ÿ Tips

- · The focal distance information (for when it is dark and hard to adjust the focus) appears for about 3 seconds in the following cases. (It will not be displayed correctly if you are using a conversion lens (sold separately)).
 - When you set the FOCUS switch B to MAN and (2) appears on the screen
 - When you rotate the focus ring while 🕞 is displayed on the screen.

Using the expanded focus (Expanded focus)

[EXPANDED FOCUS] is assigned to the ASSIGN 7 button (p. 45).

Press the ASSIGN 7 button.

[EXPANDED FOCUS] appears and the center of the screen is magnified by about 2.0 times. It will be easier to confirm the focus setting during manual focusing. The screen returns to the original size when you press the button again.

4 Notes

 Even though the image appears expanded on the screen, the recorded image is not expanded.

Ÿ Tips

 You can select a type of an expanded image displayed during the expanded focus ([EXPANDED FOCUS TYPE], p. 82).

Focusing on a distant subject (Focus infinity)

Slide the FOCUS switch **B** to INFINITY and hold it there.


appears on the screen.

To return to manual focus mode, release the FOCUS switch **B**. This function enables you to set focus on a distant subject even when the focus is automatically set on a close subject.

Notes

 This function is only available during the manual focus. It is not available during the automatic focus.

Adjusting the image brightness



You can adjust the image brightness by adjusting the iris, gain or shutter speed, or by reducing the light volume with the ND filter \boxed{B} .

4 Notes

- You cannot use the back light function and the spotlight function when iris, gain and shutter speed are adjusted manually.
- [AE SHIFT] is not effective temporarily while you adjust the iris, gain and shutter speed all manually.

Adjusting the iris

You can manually adjust the iris to control the volume of the light entering the lens. By adjusting the iris, you can change or close (GLOSE) the aperture of the lens, which is expressed as an F value between F1.6 and F11. The volume of the light increases the more that you open the aperture (decreasing F value). The volume of the light decreases the more that you close the aperture (increasing F value). The current F value appears on the screen.

① During recording or standby, set the AUTO/MANUAL switch H to MANUAL.

- When the iris is automatically adjusted, press the IRIS button [E]. A next to the iris value disappears, or the iris value appears on the screen.
- 3 Adjust the iris with the iris ring **A**. When you assign [PUSH AUTO IRIS] to one of the ASSIGN buttons, you can automatically adjust the iris while pressing and holding that ASSIGN button. See page 45 for details on the ASSIGN button.

Ϋ́ Tips

- · The F value becomes close to F3.4 as the zoom position changes from W to T even when you open the aperture by setting the F value lower than F3.4, such as F1.6.
- · The range of focus, an important effect of the aperture, is called the depth of field. The depth of field gets shallower as the aperture is opened, and deeper as the aperture is closed. Use the aperture creatively to obtain the desired effect in your photography.
- · This is handy for making the background blurred or sharp.

To adjust the iris automatically

Press the IRIS button **E**, or set the AUTO/ MANUAL switch | H to AUTO. The iris value disappears, or A appears next to the iris value.

4 Notes

• When you set the AUTO/MANUAL switch H to AUTO, other manually adjusted items (gain, shutter speed, white balance) also become automatic.

Adjusting the gain

You can adjust the gain manually when you do not want to use the AGC (automatic gain control).

- ① During recording or standby, set the AUTO/MANUAL switch | H to MANUAL.
- When the gain is automatically adjusted, press the GAIN button **C**.

- A next to the gain value disappears, or the gain value appears on the screen.
- 3 Set the gain switch F to H, M or L. The gain value set for the selected gain switch position appears on the screen. You can set the gain value for each gain switch position from [GAIN SET] of the (CAMERA SET) menu (p. 71).

To adjust the gain automatically

Press the GAIN button C, or set the AUTO/MANUAL switch \mathbf{H} to AUTO. The gain value disappears, or A appears next to the gain value.

6 Notes

 When you set AUTO/MANUAL switch H to AUTO, other manually adjusted items (iris, shutter speed, white balance) also become automatic.

ో Tips

· When you record high definition image quality (HD) movies with the gain set to [-6dB] and play them back with the data code, the gain value is displayed as [---].

Adjusting the shutter speed

You can manually adjust and fix the shutter speed. You can make a moving subject look still or emphasize the movement of a moving subject by adjusting the shutter speed.

- 1 During recording or standby, set the AUTO/MANUAL switch | to MANUAL.
- ② Press the SHUTTER SPEED button D until the shutter speed value is highlighted.
- 3 Change the shutter speed displayed on the screen by turning the SEL/PUSH EXEC dial G.

You can adjust the shutter speed in a range of 1/3 second through 1/10000 second

The denominator of the set shutter speed appears on the screen. For example,

Changing the settings of your camcorder recordings (Continued)

[100] appears on the screen when you set the shutter speed to 1/100 second. The larger the value on the screen, the faster the shutter speed.

Press the SEL/PUSH EXEC dial G to lock the shutter speed.
To readjust the shutter speed, do steps
② to ④.

Ϋ́ Tips

- It is difficult to focus automatically at a lower shutter speed. Manual focusing with your camcorder attached to a tripod is recommended.
- When recording under fluorescent lamps, sodium lamps, or mercury lamps, the picture may flicker or change colors, or may have horizontal bands of noise. You may be able to improve the situation by adjusting the shutter speed.

To adjust the shutter speed automatically

Press the SHUTTER SPEED button Dtwice, or set the AUTO/MANUAL switch H to AUTO.

The shutter speed value disappears, or **A** appears next to the shutter speed value.

4 Notes

When you set the AUTO/MANUAL switch H
to AUTO, other manually adjusted items (iris,
gain, white balance) also become automatic.

Adjusting the volume of light (ND filter)

You can record the subject clearly by using the ND filter when the recording environment is too bright.

The ND filters 1, 2 and 3 reduce the volume of light to about 1/4, 1/16 and 1/64, respectively.

If ND1 flashes during the iris automatic adjustment, set the ND filter to 1. If ND2 flashes during the iris automatic adjustment, set the ND filter to 2. If ND3 flashes during the iris automatic adjustment, set the ND filter to 3.

The ND filter indicator will stop flashing and remain on the screen.

If NDOFF flashes, set the ND filter to OFF. The ND filter icon will disappear from the screen.


4 Notes

- If you change the ND filters during recording, the movie and sound may be distorted.
- When adjusting the iris manually, the ND filter icon does not flash even if the light volume should be adjusted with the ND filter.
- If the camcorder cannot detect the ND filter position (OFF/1/2/3), ND flashes on the screen.
 Make sure that the ND filter is set correctly.

🍟 Tips

 While recording a bright subject, diffraction may occur if you close the aperture further down, resulting in a fuzzy focus (this is a common phenomenon with video cameras). The ND filter suppresses this phenomenon and gives better recording results.

Adjusting to natural color (White balance)



You can adjust and fix the white balance according to the lighting conditions of recording environment.

You can store white balance values in

memory A (A) and memory B (B), respectively. Unless a white balance is readjusted, values will remain even after the power has been turned off.

When you select PRESET, [OUTDOOR], [INDOOR] or [MANU WB TEMP] is selected, according to which one you previously set with [WB PRESET] in the (CAMERA SET) menu.

During recording or standby, set the AUTO/MANUAL switch D to MANUAL.

2 Press the WHT BAL button A.

3 Set the white balance memory switch B to any one of PRESET/A/B.

Select A or B for recording with the white balance setting stored in memory A or B.

Indicator	Shooting conditions
▲ A (Memory A) ▲ B (Memory B)	White balance values adjusted for light sources can be stored in memory A and memory B. Follow the steps in "To save the adjusted white balance value in memory A or B" (p. 31).
Outdoor ([OUTDOOR])	Recording neon signs or fireworks Recording sunset/ sunrise, just after sunset or just before sunrise Under daylight color

fluorescent lamps

Indicator	Shooting conditions
点 Indoor ([INDOOR])	Under the lighting conditions that change in many ways, such as a party hall Under strong light, such as in a photography studio Under sodium lamps or mercury lamps
Color temperature ([MANU WB TEMP])	Color temperature can be set between 2300K and 15000K (the default setting is 6500K).

Ϋ́ Tips

- · You can change the outdoor white balance setting by setting offset. Press 🖳 (one push) button C while * (outdoor) is selected and turn the SEL/PUSH EXEC dial | E | to select an offset value from -7 (bluish) to 0 (normal, the default setting) to +7 (reddish). You can also set the white balance offset value from the menu ([WB OUTDOOR LEVEL], p. 72).
- · You can change the color temperature. Set [WB PRESET] to [MANU WB TEMP], and the white balance memory switch B to PRESET, then press the \(\bigcup_{\text{\text{\text{one}}}} \) (one push) button \(\bigcup_{\text{\text{.}}} \). Turn the SEL/PUSH EXEC dial **E** until the desired temperature appears on the screen, then press the dial to set the temperature. You can also set the color temperature from the menu (WB) TEMP SET], p. 72).

To save the adjusted white balance value in memory A or B

- ① Set the white balance memory switch to A (A) or B (B) in step **3** of "Adjusting to natural color (White balance)."
- ② Capture a white subject, such as white paper, full-screen in the same lighting condition as the one in which the subject
- ③ Press the ▶ (one push) button C.

Changing the settings of your camcorder recordings (Continued)

♣ A or ♣ B starts flashing rapidly. It will stay on when the white balance adjustment is completed and the adjusted value is stored in ♣ A or ♣ B.

6 Notes

- When a white balance adjustment value has not been obtained successfully, № A or № B turns from rapid flashing to slow flashing.
 Adjust the subject appropriately and set the shutter speed to auto or around 1/50, then try adjusting the white balance again.
- It may take a long time to adjust the white balance, depending on the recording conditions.
 If you want to perform a different operation before completing the adjustment, set the white balance memory switch to another position to temporarily suspend white balance adjustment.


To adjust the white balance automatically

Press the WHT BAL button **A** or set the AUTO/MANUAL switch **D** to AUTO.

Wotes

When you set the AUTO/MANUAL switch D
to AUTO, other manual adjusted items (iris,
gain, and shutter speed) also become automatic.

Customizing the picture quality (Picture profile)



You can customize the picture quality by adjusting picture profile items such as [GAMMA] and [DETAIL].

Connect your camcorder to a TV or monitor, and adjust the picture quality while observing the picture on the TV or monitor screen.

Picture quality settings for different recording conditions have been stored in [PP1] through [PP6] as default settings.

4 Notes

When you set [x.v.Color] in the (CAMERA SET) menu to [ON], the picture profile will be disabled.

Picture profile number	Recording condition
PP1	Default settings the same as when Picture Profile is [OFF]
PP2	Default settings the same as when Picture Profile is [OFF]
PP3	Example settings of pictures recorded by a professional shoulder camcorder with ITU-709 gamma
PP4	Example settings of pictures recorded by a professional handy camcorder with PD gamma
PP5	Example settings of pictures recorded on cinema color negative film
PP6	Example settings of pictures screened with cinema color print film

- 1 During standby, press the PICTURE PROFILE button B.
- 2 Select a picture profile number with the SEL/PUSH EXEC dial A.

You can record with the settings of the selected picture profile.

3 Select [OK] with the SEL/PUSH EXEC dial A.

To cancel the picture profile recording

Select [OFF] in step 2 with the SEL/PUSH EXEC dial A.

To change the picture profile

You can change the settings stored in [PP1] through [PP6].

- 1 Press the PICTURE PROFILE button B.
- (2) Select the PICTURE PROFILE number with the SEL/PUSH EXEC dial A.
- 3 Select [SETTING] with the SEL/PUSH EXEC dial A.
- 4 Select an item to be adjusted with the SEL/PUSH EXEC dial A.
- (5) Adjust the picture quality with the SEL/ PUSH EXEC dial A.
- (6) Repeat steps (4) and (5) to adjust other items.
- ⑦ Select [➡ RETURN] with the SEL/ PUSH EXEC dial A.
- 8 Select [OK] with the SEL/PUSH EXEC dial A.

Changing the settings of your camcorder recordings (Continued)

BLACK LEVEL

To set the black level.

Item	Description and settings
[MASTER BLACK]	Sets the master black level. -15 to +15
[BLACK R]	Sets the black level of Rch. [MASTER BLACK] + [BLACK R] is the black level of Rch15 to +15
[BLACK G]	Sets the black level of Gch. [MASTER BLACK] + [BLACK G] is the black level of Gch15 to +15
[BLACK B]	Sets the black level of Bch. [MASTER BLACK] + [BLACK B] is the black level of Bch15 to +15

GAMMA

To select a gamma curve.

Item	Description and settings
[STANDARD]	Standard gamma curve
[CINEMATONE1]	Gamma curve 1 for producing tone of film camera images
[CINEMATONE2]	Gamma curve 2 for producing tone of film camera images
[ITU709]	Gamma curve that corresponds to ITU-709. Gain in low intensity area: 4.5
[G5.0]	Gamma curve with 5.0 of a low intensity area gain
[PD]	Gamma curve for producing tone similar to DSR-PD series
[x.v.]	Gamma curve similar to x.v.Color

BLACK GAMMA

To correct gamma in low intensity area.

Item	Description and settings
[RANGE]	Selects a correcting range. HIGH / MIDDLE / LOW
[LEVEL]	Sets the correcting level7 (maximum black compression) to +7 (maximum black stretch)

KNEE

To set knee point and slope for video signal compression to prevent over-exposure by limiting signals in high intensity areas of the subject to the dynamic range of your camcorder.

Item	Description and settings
[MODE]	Selects a mode either automatic or manual. [AUTO] : to set the knee point and slope automatically. [MANUAL] : to set the knee point and slope manually.
[AUTO SET]	Sets the maximum point and sensitivity in the automatic mode. [MAX POINT] : Sets the maximum point. 90% to 100% [SENSITIVITY] : Sets the sensitivity. HIGH/MIDDLE/LOW
[MANUAL SET]	Sets the knee point and slope manually. [POINT] : Sets the knee point. 75% to 105% [SLOPE] : Sets the knee slope. -5(gentle) to +5(steep)

COLOR MODE

To set type and level of colors.

Item	Description and settings
[TYPE]	Selects a type of colors.
	[STANDARD] : Standard colors
	[CINEMATONE1]: Film camera image-like colors good with
	[GAMMA] set to [CINEMATONE1]
	[CINEMATONE2]: Film camera image-like colors good with
	[GAMMA] set to [CINEMATONE2]
	[ITU709 MATRIX]: Colors corresponding to ITU-709
[LEVEL]	Sets a color level when you set [TYPE] to the settings other than
	[STANDARD].
	1 (close to color settings of [STANDARD]) to 8 (color settings of the
	selected type)

COLOR LEVEL

To set the color level.

Item	Description and settings
	-7 (light) to +7 (dark), -8: black and white

COLOR PHASE

To set the color phase.

Item	Description and settings	
	-7 (greenish) to +7 (reddish)	·

Changing the settings of your camcorder recordings (Continued)

COLOR DEPTH

To set the color depth for each color phase.

This function is more effective for chromatic colors and less effective for achromatic colors. The color looks deeper as you increase the setting value to more positive side, and lighter as you decrease the value to more negative side. This function is effective even if you set [COLOR LEVEL] to [-8] (black and white).

Item	Description and settings
[R]	-7 (light red) to +7 (deep red)
[G]	-7 (light green) to +7 (deep green)
[B]	-7 (light blue) to +7 (deep blue)
[C]	-7 (light cyan) to +7 (deep cyan)
[M]	-7 (light magenta) to +7 (deep magenta)
[Y]	-7 (light yellow) to +7 (deep yellow)

WB SHIFT

To set items for the white balance shift.

Item	Description and settings
[FILTER TYPE]	Selects a color filter type for the white balance shift. [LB-CC] : Film type (color conversion and correction) [R-B] : Video type (correction of R and B levels)
[LB[COLOR TEMP]]	Sets a color temperature offset value9 (bluish) to +9 (reddish)
[CC[MG/GR]]	Sets a color correct offset value9 (greenish) to +9 (magentish)
[R GAIN]	Sets an R level9 (low R level) to +9 (high R level)
[B GAIN]	Sets a B level9 (low B level) to +9 (high B level)

DETAIL

To set items for the detail.

Item	Description and settings
[LEVEL]	Sets the detail level. -7 to +7
[MANUAL SET]	[ON/OFF] : Turns on and off the manual detail adjustment. [ON] : Enables the manual detail adjustment (automatic optimization will not be performed). [OFF] : Disables the manual detail adjustment. [V/H BALANCE] : Sets the vertical (V) and horizontal (H) balance of DETAIL. -2 (off to the vertical (V) side) to +2 (off to the
	[B/W BALANCE]: Selects the balance of the lower DETAIL (B) and the upper DETAIL (W). TYPE 1 (off to the lower DETAIL (B) side) to TYPE 5 (off to the upper DETAIL (W) side)
	[BLACK LIMIT]: Sets the limit level of the lower DETAIL (B). 0 (Low limit level: likely to be limited) to 7 (High limit level: not likely to be limited)
	[WHITE LIMIT]: Sets the limit level of the upper DETAIL (W). 0 (Low limit level: likely to be limited) to 7 (High limit level: not likely to be limited)
	[CRISPENING] : Sets the crispening level. 0 (shallow crispening level) to 7 (deep crispening level)
	[HI-LIGHT DETAIL]: Sets the DETAIL level in the high intensity areas. -2 to +2

Changing the settings of your camcorder recordings (Continued)

SKINTONE DETAIL

To adjust the detail of skintone areas to reduce wrinkles.

Item	Description and settings		
[ON/OFF]	Suppresses details in skin-tone areas to reduce wrinkles. Select [ON] when you want to use this function. You can also select other areas.		
[LEVEL]	Sets the adjustment level. 1 (less adjust the detail) to 8 (more adjust the detail)		
[COLOR SEL]	Sets color items for the detail adjustment. [PHASE] : Sets the color phase. 0 (purple) → 32 (red) → 64 (yellow) → 96 (green) → 127 (blue)		
	[RANGE] : Sets the color range. 0 (selects no color), 1 (narrow: selects a single color) to 31 (wide: selects multiple colors in similar color phases and saturation) The detail will not be adjusted when you set [RANGE] to 0.		
	[SATURATION]: Sets the color saturation. 0 (selects a light color) to 31 (selects a deep color)		
	[REVERSE] : Reverses the selected color range. If you execute this function when a color has been selected, colors that have not been selected will be selected instead.		
	[Y LEVEL] : Sets the color brightness. 0 (selects a dark color) to 31 (selects a bright color)		
	[Y RANGE] : Sets the color brightness range. 1 (narrows the brightness range) to 32 (expands the brightness range)		

COPY

To copy the settings of the picture profile to another picture profile number.

RESET

To reset the picture profile to the default setting.

To copy the picture profile setting to another picture profile number

See page 32 for the location of the buttons.


- 1) Press the PICTURE PROFILE button B.
- 2) Select the picture profile number that you want to copy from with the SEL/ PUSH EXEC dial A.
- ③ Select [SETTING] \rightarrow [COPY] with SEL/PUSH EXEC dial A.
- 4 Select the number of the picture profile that you want to copy to with the SEL/ PUSH EXEC dial A.
- (5) Select [YES] with the SEL/PUSH EXEC dial A.
- ⑥ Select [≤ RETURN] → [OK] with the SEL/PUSH EXEC dial A.

To reset the picture profile settings

You can reset the picture profile settings by each picture profile number. You cannot reset all picture profile settings at once. See page 32 for the location of the buttons.

- 1) Press the PICTURE PROFILE button B.
- 2) Select the number of the picture profile that you want to reset with the SEL/ PUSH EXEC dial A.
- ③ Select [SETTING] \rightarrow [RESET] \rightarrow with the SEL/PUSH EXEC dial A.

Audio setup



Channel setting

1 Select input sources with the CH1 (INT MIC/INPUT1) switch [C] and the CH2 (INT MIC/INPUT1/INPUT2) switch

See the table below for the recording channels.

When the CH1 switch is set to INT MIC

CH2 switch position	Input channel and source	
INT MIC	Internal microphone CH1 (L)	
	Internal microphone CH2*	
INPUT1	Internal microphone CH1 (mono)	
	XLR INPUT1 ← CH2**	
INPUT2	Internal microphone CH1 (mono)	
	XLR INPUT2 ◆ CH2**	

When the CH1 is set to INPUT1

CH2 switch position	Input channel and source	
INT MIC	XLR INPUT1 ◆	CH1
	Internal microphone (mono)	CH2**
INPUT1	XLR INPUT1	CH1
		CH2**
INPUT2	XLR INPUT1 ◆	CH1
	XLR INPUT2 ◆	CH2**

- * The recording level of channel 2 is synchronized with that of channel 1 when only the internal microphone is used. The recording level of channel 2 is controlled with the CH1 (AUDIO LEVEL) dial and the CH1 (AUTO/ MAN) switch.
- ** You can adjust the recording levels of channel 1 and channel 2 separately.
- ② Set the INPUT1 switch to an appropriate position for the microphone connected to the INPUT1 jack .

- LINE: For inputting sound from an audio device
- MIC: For inputting sound from an external microphone that does not support the +48V power source.
- MIC+48V:For inputting sound from a device that supports the +48V power source including the supplied microphone.

When you connect a microphone to the INPUT2 jack, set the INPUT2 switch to an appropriate position for that microphone.

O Notes

- Do not operate the INPUT1/INPUT2 switches during recording to prevent noise from being recorded.
- When you connect a device that supports the +48V power source to the INPUT1 or INPUT2 jack, set the INPUT1/INPUT2 switches to MIC prior to connecting the device. When you disconnect the device, set the INPUT1/INPUT2 switch to MIC first, then disconnect it.
- When you connect a microphone that does not support the +48V power source to the INPUT1 or INPUT2 jack, set the INPUT1/INPUT2 switch to MIC. If you use it with the INPUT1/ INPUT2 switch set to MIC+48V, it may be damaged or the recorded sound may be distorted.

Adjusting the volume

You can adjust the volume of an internal microphone or a microphone connected to the INPUT1/INPUT2 jacks.

🍟 Tips

- See page 10 for details on attaching the supplied microphone, and page 39 on the CH1 (INT MIC/INPUT1) and the CH2 (INT MIC/ INPUT1/INPUT2) switches.
- ① Set the AUTO/MAN (CH1/CH2) switch E of the channel to be adjusted to MAN.

hm1 appears on the screen.

2 Turn the AUDIO LEVEL dial F to adjust the volume during recording or standby.


To restore automatic adjustment

Set the AUTO/MAN (CH1/CH2) switch [E] of the manually adjusted channel to AUTO.

Ϋ́ Tips

- · To check other audio settings, press the STATUS CHECK button G
- · You can select [LINEAR PCM] or [DOLBY DIGITAL] when recording in high definition image quality (HD). (The default setting is [LINEAR PCM]. See page 78 for details.)
- For other settings, see the 🎝 🖟 (AUDIO SET) menu (p. 78).


Setting the headphone sound



You can select the channel, CH1 or CH2, to output from the headphone. See [HEADPHONE OUT] on the sound at

STEREO MIX (p. 78).

Acquiring location information (HXR-NX5E/NX5P)



Set the GPS switch to ON.

appears, and your camcorder starts trying to triangulate. When your camcorder triangulates successfully, it will record the location information at the time movies were recorded.

4 Notes

· The indicator changes according to the strength of GPS signal reception.

or or o signar reception.			
Tri- angulating status	GPS indicators	GPS reception status	
Function off	No indicator	The GPS switch is set to OFF, or the GPS receiver is not functioning normally.	
Difficult	×O	The camcorder cannot find a GPS signal, therefore, it cannot triangulate. Use the camcorder in an open area.	
Searching	X ⊙	The camcorder is searching the GPS signal. It may take several minutes until the camcorder triangulates.	
Tri- angulating	×	The camcorder is receiving a weak GPS signal.	
Tri- angulating	×iI	The camcorder is receiving a GPS signal, and can acquire location information.	
Tri- angulating	×iII	The camcorder is receiving a strong GPS signal, and can acquire location information.	

· The GPS switch is set to ON in the default setting. Movies recorded during triangulation by GPS will be recorded with location information. If you do not want to record location information, set the GPS switch to OFF.

Changing the settings of your camcorder recordings (Continued)

- If the GPS indicator does not become a triangulating status indicator even after several minutes, the camcorder is having trouble with receiving GPS signals. You may start recording if you do not need to record location information, or go to a location with access to the open sky.
- The camcorder can hardly receive GPS signals indoors or near tall buildings. Go to a location with access to the open sky and turn on the GPS switch again.
- Even if the camcorder is turned off, the GPS function is working as long as the GPS switch is set to ON. Make sure that the GPS switch is set to OFF during take off and landing of an airplane.
- Even if a triangulating status indicator is displayed, the camcorder may not record the GPS information continuously, depending on the condition of GPS signal reception.

Recording with the SMOOTH SLOW REC function

Fast moving subjects and actions, which cannot be captured under the general recording conditions, can be recorded in smooth moving slow-motion.

This is useful for recording fast actions such as a golf or tennis swing.

- 1 Press the MODE button.
- 2 On the LCD screen, select [CAMERA] → [SMOOTH SLOW REC].
- 3 Select the recording media and image quality → recording time.

You can select the recording time from [3sec], [6sec] and [12sec].

4 Press the record button.

A recording of the length selected as the recording time is stretched by 4 times and recorded as a slow-motion movie.

Recording ends when [Recording...] disappears from the screen.

To cancel [SMOOTH SLOW REC], press the MODE button.

To change the setting


Press the MENU button, and select the setting to be changed.

■ REC MODE

You can select the record mode from [1080/50i FX], [1080/50i FH], [1080/50i HQ], or [1080/50i LP] for smooth slow recording.

REC TIMING

You can use this to select when recording starts in relation to when the record button (handle record button) is pressed.



* The default setting is [START TRIGGER].

4 Notes

- · Sounds cannot be recorded.
- The shutter speed is automatically set to 1/215 second when you start [SMOOTH SLOW REC]. (You cannot set a slower shutter speed than 1/215 second.)
- The recording time may be shorter than the set time, depending on recording conditions.
- The image quality is lower than with the regular recording.
- The simultaneous recording on the memory card and the flash memory unit is not available.

- · The longer the recording time, the poorer the image quality.
- The camcorder does not perform relay recording with the memory cards during [SMOOTH SLOW REC]. If the space on the memory card is insufficient, the camcorder records movies only as long as there is space available.
- · The time of the movie recorded using [SMOOTH SLOW REC] is recorded after being converted to slow-motion, not the time when the movie is actually shot.
- · Progressive recording is not available for [SMOOTH SLOW REC]. The progressive setting is changed to the interlace setting automatically.
- · [SMOOTH SLOW REC] is not available when the recording format of high definition image quality (HD) is set to 720/50p.
- · Even if you change the record mode with [HD REC MODE], the record mode of the standard definition image quality (SD) does not change.

Setting time data

The camcorder records movies accompanied by time data, such as time code and user bit.

Display the setting screen by pressing the MENU button → select (TC/UB SET) with the SEL/PUSH EXEC dial.

Presetting the time code

- 1) Select [TC PRESET] with the SEL/ PUSH EXEC dial.
- ② Select [PRESET] with the SEL/PUSH EXEC dial.
- 3 Select the first 2 digits with the SEL/ PUSH EXEC dial.
 - You can set the time code between 00:00:00:00 and 23:59:59:24.
- 4 Set other digits by repeating step 3.
- (5) Select [OK] with the SEL/PUSH EXEC dial

To reset the time code

You can reset the time code (00:00:00:00).

Select [RESET] in step 2 of "Presetting the time code."

To reset the time code using the Wireless Remote Commander

You can reset the time code (00:00:00:00) also by pressing the TC RESET button on the Wireless Remote Commander

Presetting the user bit

- ① Select [UB PRESET] with the SEL/ PUSH EXEC dial.
- ② Select [PRESET] with the SEL/PUSH EXEC dial.
- 3 Select the first 2 digits with the SEL/ PUSH EXEC dial.
- (4) Set other digits by repeating step (3).
- Select [OK] with the SEL/PUSH EXEC dial.

To reset the user bit

You can reset the user bit (00 00 00 00). Select [RESET] in step ② of "Presetting the user bit."


Synchronizing the time code of this camcorder with that of another camcorder

You can synchronize the time code of this camcorder with the time code of another camcorder.

The camcorder that generates the time code must be set to FREE RUN (the time code advances regardlessly).

- 1) Set [TC RUN] and [TC MAKE] in [Decoration of the content of the (TC/UB SET) as follows:
 - [TC MAKE]: [PRESET]
 - [TC RUN]: [FREE RUN]
- ② Set the TC LINK switch of this. camcorder to IN, and connect the TC LINK IN/OUT jack and the TC OUT iack of the other camcorder with a cable.

Changing the settings of your camcorder recordings (Continued)



The time code of this camcorder synchronizes with that of the connected camcorder. [TC IN] appears on this camcorder screen.

Following conditions must be satisfied to input time code.

- The TC LINK switch is set to IN, and there are input time code data.
- · Recording standby
- The frame rate of this camcorder time code and that of the input time code are the same.
- The input time code is advancing.



The time code remains synchronized, even if the other camcorder is disconnected.

4 Notes


- Connect the camcorders when both camcorders are recording standby.
- If the frame rate of the input time code differ from that of this camcorder, or the input time code is not advancing, the input time code is not regarded as effective time code. The input time code to the TC LINK IN/OUT jack are as follows:
 - 50i/25p: 25-frame

Synchronizing the time code of another camcorder with that of this camcorder

You can synchronize the time code of another camcorder with the time code of this camcorder.

The camcorder that generates the time code must be set to FREE RUN (the time code advances regardlessly).

- ① Set the time code of this camcorder with [TC RUN] and [TC MAKE] in [CODE | CTC/UB SET).
- ② Set the TC LINK switch of this camcorder to OUT, and connect the TC LINK IN/OUT jack and the TC IN jack of the other camcorder with a cable.



Notes

- The output time code from the TC LINK IN/ OUT jack are as follows:
 - 50i/25p: 25-frame

🍹 Tips

 You can output time code from this camcorder also when the camcorders are connected via the SDI jacks.


Assigning the functions to the ASSIGN buttons

Some functions can be assigned to the ASSIGN buttons for use. You can assign a single function to any one of the ASSIGN 1 to 7 buttons.


Functions you can assign to the **ASSIGN** buttons

The buttons in parentheses indicate that the functions are assigned to the buttons by default.

- EXPANDED FOCUS (p. 28) (ASSIGN 7
- PUSH AUTO IRIS (p. 28)
- HYPER GAIN (p. 71)
- IRIS RING ROTATE (p. 72)
- AE SHIFT (p. 72) (ASSIGN 5 button)
- BACK LIGHT (p. 73)
- · SPOTLIGHT (p. 73)
- STEADYSHOT (p. 73)
- FOCUS MACRO (p. 74)
- D.EXTENDER (p. 75)
- FADER (p. 75)
- COLOR BAR (p. 76)
- ZEBRA (p. 81) (ASSIGN 4 button)
- PEAKING (p. 81)
- MARKER (p. 81)
- REC LAMP[F] (p. 86)
- REC LAMP[R] (p. 86)
- VISUAL INDEX (p. 47) (ASSIGN 6 button)
- MODE (p. 57)



- 1 Press the MENU button B.
- 2 Select \blacksquare (OTHERS) \rightarrow [ASSIGN **BUTTON1** with the SEL/PUSH EXEC dial A.




3 Select the ASSIGN button to which you want to assign a function with the SEL/PUSH EXEC dial A.

Assigning the functions to the ASSIGN buttons (Continued)


- [-----] appears if no function is assigned to the ASSIGN button.
- 4 Select the function that you want to assign with the SEL/PUSH EXEC dial A.
- 5 Select [OK] with the SEL/PUSH EXEC dial [A].
- 6 Select [← RETURN] with the SEL/PUSH EXEC dial A.
- 7 Press the MENU button B to hide the menu screen.

Playback




You can play back movies as follows:

Slide the POWER switch to ON.



2 Press the VISUAL INDEX button.

The VISUAL INDEX screen appears after a few seconds.



You can display the VISUAL INDEX screen also by pressing the MODE button, followed by touching $[PLAY] \rightarrow [VISUAL\ INDEX]$ on the screen.

You can turn on or off the time and date display on the thumbnails by pressing the DISPLAY button

Playback (Continued)

3 Play back movies.


1 Touch the recording media you want to play back.

A: Memory card A
B: Memory card B

Ext: Flash memory unit

2 Touch the playback mode, and select the desired image quality of movies.

Playback mode




HD: High definition image quality (HD)

SDE: Standard definition image quality (SD)

3 Touch twice the thumbnail of the movie you want to play back.

The first touch will show the information on the movie at the lower part of the screen.



- A Date and time of recording started
- **B** Resolution
- C Frame rate
- D Record mode
- **E** Duration
- F Time code of recording started

Time code will not be displayed correctly when you play back recording media with no time code, or recording media with time code that your camcorder does not support.

GPS data (HXR-NX5E/NX5P)


Appears on the movie that was recorded with the GPS switch set to ON.

H LPCM recording

Appears when audio is recorded in Linear PCM. This does not appear for movies in the standard definition image quality (SD).

I▶I appears with the movie that has been most recently played back or recorded. If you touch the
movie with I▶I, you can continue playback from the previous time.

Your camcorder starts playing the selected movie.



6 Notes

· You may not be able to play back movies recorded on other camcorders.

Ϋ́ Tips

- · When playback from the selected movie reaches the last movie, the screen returns to the VISUAL INDEX screen.
- Touch ☐ during pause to play back movies slowly.
- As you repeat touching \(\sqrt{\emp} \) \(\left(\mathbb{D} \right) \) during playback, movies are played back as fast as about 5 times \rightarrow about 10 times \rightarrow about 30 times \rightarrow about 60 times.
- · Reduced-size images which enable you to view many movies at the same time on the VISUAL INDEX screen are called "thumbnails."
- · You can operate playback using the PREV/PLAY/NEXT/STOP/PAUSE/SCAN/SLOW buttons on the camcorder

To adjust the volume

Adjust the volume with the VOLUME buttons.

To return to the recording mode

Press the VISUAL INDEX button.

Viewing still images

You can create still images by capturing scenes from movies that you recorded on your camcorder (p. 60).


View still images.

1 Touch the recording media you want to view.

A: Memory card A ■B: Memory card B EXT: Flash memory unit


Playback (Continued)

② Touch the playback mode, then select 🗖 (still image).



3 Touch twice the thumbnail of the still image you want to view.

The first touch will show the information on the still image at the lower part of the screen.



- A Date and time of recording
- **B** Resolution
- C Image size
- D Playback folder
- E Playback folder edge


Indicates that this is the first or the last page of the playback folder. This does not appear when there is only 1 playback folder.

F GPS data (HXR-NX5E/NX5P)


Appears on a still image that was created from a movie recorded with the GPS switch set to ON.

pappears on a still image recorded on a memory card.

Your camcorder displays the selected still image.



Changing/checking the settings in your camcorder



Changing the screen

You can turn on and off the display of the time code, and other information on the screen.

Press the DISPLAY button B.

The screen indicators turn on (displayed) and off (not displayed) as you press the button.

In the recording mode, the screen changes like "detailed display → simple display → no display" as you press the button.

Ϋ́ Tips


· You can display the screen indicators during playback on a TV. Select [ALL OUTPUT] of [DISPLAY OUTPUT] (p. 84).

Displaying recording data (Data code)

You can display information, including date, time, camera data and GPS triangulation data (HXR-NX5E/NX5P) automatically stored during recording on the screen during playback.

Press the DATA CODE button A during playback or pause.

The screen changes like "date and time display → camera data display → GPS triangulation data (HXR-NX5E/NX5P) \rightarrow no display" as you press the button.



- 1 SteadyShot
- 2 Exposure

AUTO appears during playback of the movie recorded with the iris, gain or shutter speed automatically adjusted. MANUAL appears during playback of the movie recorded with the iris, gain or shutter speed manually adjusted.

3 Iris

CLOSE appears in the iris value display area during playback of the movie recorded with the iris manually adjusted to its maximum value.

- 4 Gain
- 5 Shutter speed
- 6 White balance

Changing/checking the settings in your camcorder (Continued)

pwg appears during playback of the movie recorded with [MANU WB TEMP].


6 Notes

- The exposure correction value (EV), shutter speed, iris and flash on/off will be displayed during viewing still images.
- When you play back the memory card on other devices, the camera data may be displayed incorrectly. Confirm the correct camera data on your camcorder.
- When GPS triangulation data is displayed, latitude, longitude, date and time of recording are displayed in the data code area (HXR-NX5E/NX5P).
- You can select UTC time or local time for the date and time display with [GPS TIME DISPLAY] in the menu (HXR-NX5E/NX5P).
- If you record without receiving GPS data, [----] and [--:---] will be displayed (HXR-NX5E/NX5P).

Displaying the settings in your camcorder (Status check)

You can check the settings of the following items.

- Audio setup such as microphone volume level (p. 78)
- Output signal setup ([VIDEO OUT], etc.) (p. 77)
- Functions assigned to the ASSIGN buttons (p. 45)
- Camera setup (p. 71)
- Record button setup (p. 23)
 You can check the record button setting.




Recording media information
 You can check the estimated used and free
 spaces.



Battery Info
 You can check the remaining capacity of
 the attached battery.



1 Press the STATUS CHECK button D.



2 Turn the SEL/PUSH EXEC dial C until a desired display shows up on the screen.

AUDIO → OUTPUT → ASSIGN → CAMERA → REC BUTTON SET → MEDIA INFO → BATTERY INFO

Setup items are displayed according to the settings of the camcorder when it is turned on.

To hide the display


Press the STATUS CHECK button **D**.

Connecting a monitor or a TV

Playback image quality depends on the type of monitor or TV, or the jacks used to make the connection.

You do not need an audio cable to connect a monitor that supports SDI audio input via an SDI cable. If the monitor does not support SDI audio input, you must connect the red and white jacks with an audio cable. When you connect the monitor with the component video cable, you must connect the red and white jacks with an A/V connecting cable.

Set \leftarrow (REC/OUT SET) menu \rightarrow [VIDEO OUT] \rightarrow [OUTPUT SELECT] to output signals from the respective jacks.



6 Notes

• Select the jack to output signals with [OUTPUT SELECT].

[OUTPUT SELECT] setting	SDI OUT	HDMI OUT	COMPONENT OUT	VIDEO OUT
[SDI]	0	0	-	-
[HDMI]	-	0	_*1	_*2
[COMPONENT]	-	-	0	_*3
[VIDEO]	-	-	-	0

^{*1} When the HDMI OUT jack is not connected, signals are output from the COMPONENT OUT jack.

• Output resolution depends on the settings of [SDI/HDMI/COMPONENT].

	[SDI/HDMI/	Output resolution			
HD/SD	COMPONENT] setting	SDI OUT	HDMI OUT	COMPONENT OUT	VIDEO OUT
	720p/576i	720p	720p	720p	576i
HD	1080i/576i	1080i	1080i	1080i	576i
пр	576p	No output	576p	576p	576i
	576i	576i	576i	576i	576i
	720p/576i	576i	576i	576i	576i
SD	1080i/576i	576i	576i	576i	576i
SD	576p	No output	576p	576p	576i
	576i	576i	576i	576i	576i

- If you set [SDI/HDMI/COMPONENT] to [576p], no signals are output from the SDI OUT jack.
- · Use an HDMI cable with the HDMI logo.
- Images are not output from the HDMI OUT jack of your camcorder, if copyright protection signals are recorded in the movies.
- · Images and sounds may not be reproduced correctly on some monitors or TVs.
- · Do not connect the output jacks of the camcorder with the output jacks of the monitor or TV. A malfunction may be caused.
- This camcorder is not compatible with "BRAVIA" sync.

aqiT 🌣

· HDMI (High-Definition Multimedia Interface) is an interface to send both video/audio signals. The HDMI OUT jack outputs high quality images and digital audio.

^{*2} When the HDMI OUT and COMPONENT OUT jacks are not connected, signals are output from the VIDEO OUT jack.

^{*3} When the COMPONENT OUT jack is not connected, signals are output from the VIDEO OUT jack.

Connecting a monitor or a TV (Continued)


If your TV/VCR has a 21-pin adaptor (EUROCONNECTOR)

Use a 21-pin adaptor (commercially available) to view playback images.




Operating the MODE menu

You can edit the recorded movies, format recording media, etc.



- 1 Set the POWER switch to ON.
- 2 Press the MODE button.




3 Touch the desired category.

Example: [EDIT] category



4 Touch the desired item.

Example: [DELETE]



5 Operate following the instructions on the screen.

To hide the MODE menu screen

Touch X, or press the MODE button.

To return to the previous screen

Touch ◆.

Protecting recorded images (Protect)

Protect movies and still images to avoid deleting them by mistake.


Ÿ Tips

- You can also protect movies and still images by pressing the MENU button on the VISUAL INDEX screen or the playback screen.
- 1 Press the MODE button.
- 2 Touch [EDIT] → [PROTECT].
- 3 To protect movies, touch [MOVIE PROTECT] → select the desired recording media and image quality.

To protect still images, touch [PHOTO PROTECT] → select the desired recording media.

4 Touch the movies or still images to be protected.

• is displayed on the selected images.



Ϋ́ Tips

- Press and hold the image down to preview the image. Touch to return to the previous screen.
- You can select up to 100 images at one time.

5 Touch $\bigcirc \mathbb{K} \to [YES] \to \bigcirc \mathbb{K}$.

To undo the protection of movies and still images

Touch the movie or still image marked with o→ in step 4.

on disappears.

Using the Playlist of movies


The Playlist is a list showing thumbnails of the movies that you have selected.

The original movies are not changed even if you edit or erase the movies added to the Playlist.

Creating the Playlist

Wotes

- High definition image quality (HD) movies and standard definition image quality (SD) movies are added to individual Playlists.
- Press the MODE button.
- 2 Touch [EDIT] → [PLAYLIST EDIT] → [ADD] → select the desired recording media and image quality.
- 3 Touch the movie to be added to the Playlist.
 - ✓ is displayed on the selected movies.



Ϋ́ Tips

- · Press and hold the image down to preview the image. Touch **5** to return to the previous screen.
- 4 Touch $OK \rightarrow [YES] \rightarrow OK$.

4 Notes

- · Do not remove the battery pack, the AC Adaptor/Charger or the recording media that contains the movies from your camcorder during the operation. It may damage the recording media.
- · You cannot add still images to a Playlist.

Ÿ Tips

- · You can add a maximum of 999 high definition image quality (HD) movies, or 99 standard definition image quality (SD) movies to the Playlist.
- · You can also add movies by pressing the MENU button on the VISUAL INDEX screen, the playback screen or the Playlist screen.

Playing the Playlist

- Press the MODE button.
- 2 Touch [PLAY] \rightarrow [PLAYLIST] \rightarrow select the desired recording media and image quality.

Movies added to the Playlist appear.

3 Touch the movie you want to play back.

The Playlist is played back from the selected movie to the end, then the screen returns to the Playlist screen.

To erase unnecessary movies from the Playlist

- 1 Press the MODE button.
- ② Touch [EDIT] → [PLAYLIST EDIT] → [ERASE] → select the desired recording media and image quality.
 - · To erase all the movies from the Playlist, touch [EDIT] \rightarrow [PLAYLIST EDIT] \rightarrow

Using the Playlist of movies (Continued)

[ERASE ALL] → select the desired recording media and image quality.

- 3 Touch the movie to be erased from the list.
 - ✓ is displayed on the selected movies.

🌣 Tips

- Press and hold the image down to preview the image. Touch to return to the previous screen.
- ④ Touch OK → [YES] → OK.

Ϋ́ Tips

- Even if you erase a movie from a Playlist, the original movie is not deleted.
- You can also erase movies by pressing the MENU button on the Playlist screen or the Playlist playback screen.

To change the order within the Playlist

- 1 Press the MODE button.
- ② Touch [EDIT] → [PLAYLIST EDIT] → [MOVE] → select the desired recording media and image quality.
- ③ Touch the movie to be moved.✓ is displayed on the selected movies.

ΰ Tips

- Press and hold the image down to preview the image. Touch
 to return to the previous screen.
- 4 Touch OK.
- ⑤ Select the destination with ◆/→.
- **⑥** Touch \overline{OK} → [YES] → \overline{OK} .

Ϋ́ Tips

- When you select multiple movies, the movies are moved following the order appearing in the Playlist.
- You can also reorder movies by pressing the MENU button on the Playlist screen.

Capturing still images from a movie

You can save a selected frame from a recorded movie as a still image.

1 Press the MODE button.


- 2 Touch [EDIT] → [PHOTO CAPTURE] → select the desired recording media and image quality.
- 3 Touch the movie to be captured.

The selected movie starts playback.

4 Touch ▶ □ at the point where you want to capture.

The movie pauses. Play and pause toggles as you press [

After you select the point with ▶ III, make fine adjustment with ↓ III .



Returns to the beginning of the selected movie

5 Touch OK.

The captured still image is saved on the recording media selected for movies. When capturing is finished, the screen returns to pause.

- To continue capturing, touch , then repeat steps from step 4.
- To capture a still image from another movie, touch , then repeat steps from step 3. If you change the recording media and the

image quality of the movies, start again from the beginning.

4 Notes

- · The image size is fixed depending on the image quality of the movie:
 - [2.1M] with high definition image quality
 - [0.2M] in 16:9 (wide) with standard definition image quality (SD)
 - [VGA(0.3M)] in 4:3 with standard definition image quality (SD)
- · The recording media where you want to save still images should have enough free space.
- · The recording date and time of captured still images is the same as the recording date and time of the movies.
- · If the movie you are capturing from has no data code, the recording date and time of the still image will be the date and time you captured from the movie

Dividing a movie

You can divide a movie at a designated point.


- 1 Press the MODE button.
- 2 Touch [EDIT] \rightarrow [DIVIDE] \rightarrow select the desired recording media and image quality.
- 3 Touch the movie to be divided.

The selected movie starts playback.

4 Touch I at the point where you want to divide.

The movie pauses. Play and pause toggles as you press .

After you select the point with II, make



Returns to the beginning of the selected movie

5 Touch $[OK] \rightarrow [YES] \rightarrow [OK]$.

4 Notes

- · You cannot restore movies once they are
- · Do not remove the battery pack, the AC Adaptor/Charger or the recording media that contains the movies from your camcorder during the operation. It may damage the recording media.

Dividing a movie (Continued)

- If you divide the original movie, the movie added to the Playlist will also be divided.

Ϋ́ Tips

 You can also divide a movie by pressing the MENU button on the VISUAL INDEX screen or the playback screen of movies.

Deleting movies and still images

You can free media space by deleting movies and still images from recording media.

4 Notes

- You cannot restore images once they are deleted.
- Do not remove the battery pack, the AC Adaptor/Charger or the recording media that contains the movies or still images from your camcorder during the operation. It may damage the recording media.
- You cannot delete protected movies and still images. Undo the protection of the movies and still images to delete them, before you try to delete them (p. 58).
- If the deleted movie is included in the Playlist (p. 59), the movie added to the Playlist is deleted also from the Playlist.
- Save important movies and still images in advance (p. 88).


ϔ Tips

- · You can select up to 100 images at one time.
- To delete all data recorded on the recording media and recover all the recordable space of the media, format the media (p. 65).
- 1 Press the MODE button.
- 2 Touch [EDIT] → [DELETE].
- 3 To delete movies, touch [MOVIE DELETE] → select the desired recording media and image quality.

To delete still images, touch [PHOTO DELETE] → select the desired recording media.

4 Touch the movies or still images to be deleted.

✓ is displayed on the selected images.



Ϋ́ Tips

· Press and hold the image down to preview the image. Touch \(\bigcup \) to return to the previous screen.

5 Touch
$$\bigcirc \mathbb{K} \rightarrow [YES] \rightarrow \bigcirc \mathbb{K}$$
.

To delete all movies/still images at one time

In step 3, touch [MOVIE DELETE ALL] → select the desired recording media and image quality \rightarrow [YES] \rightarrow [YES] \rightarrow \bigcirc K.

· To delete all still images at one time, touch [PHOTO DELETE ALL] → select the desired recording media \rightarrow [YES] \rightarrow [YES] \rightarrow \bigcirc K.

4 Notes

· Protected movies and still images are not deleted from the recording media.

Ϋ́ Tips

· You can also delete images by pressing the MENU button on the VISUAL INDEX screen or the playback screen of movies and still images.

Dubbing movies/ copying still images

Dubbing movies

You can dub movies recorded on the memory card to the flash memory unit. Insert the memory card, and attach the flash memory unit to your camcorder before the operation.

4 Notes

- · If there is no image database file on the flash memory unit, you cannot dub movies. in this case, press the MODE button, then touch [MANAGE MEDIA] → [REPAIR IMAGE DB FILE $\rightarrow [FXT]$, to create the image database file.
- · Connect your camcorder to the wall outlet (wall socket) using the supplied AC Adaptor/Charger to prevent your camcorder from running out of power during the operation.

Ÿ Tips

· The original movie will not be deleted after dubbing.

Press the MODE button.

2 Touch [DUB/COPY] \rightarrow [MOVIE] DUB].

3 Touch the type of dubbing.

[DUB by select]: To select movies and dub


[DUB ALL]: To dub all movies recorded

4 Touch the recording media and the image quality of the movie to be dubbed.

5 Select the movie to be dubbed.

[DUB by select]: Touch the movie to be dubbed, and mark it with

✓. You can select multiple movies.



Estimated remaining capacity of the flash memory unit



 Press and hold the image down to preview the image. Touch
to return to the previous screen.

When you select [DUB ALL], follow the instructions on the screen

6 Touch $\bigcirc \mathbb{K} \to [YES] \to \bigcirc \mathbb{K}$.

Copying still images

You can copy still images recorded on the memory card to the flash memory unit. Insert the memory card, and attach the flash memory unit to your camcorder before the operation.

Notes

- Connect your camcorder to the wall outlet (wall socket) using the supplied AC Adaptor/Charger to prevent your camcorder from running out of power during the operation.
- 1 Press the MODE button.
- 2 Touch [DUB/COPY] → [PHOTO COPY].

3 Touch the type of copying.

[COPY by select]: To select still images and copy

[COPY ALL]: To copy all still images recorded

- 4 Touch the recording media of the still image to be copied.
- 5 Select the still image to be copied.

[COPY by select]: Touch the still image to be copied, and mark it with . You can select multiple still images.

Ϋ́ Tips

 Press and hold the image down to preview the image. Touch to return to the previous screen.

When you select [COPY ALL], follow the instructions on the screen.

6 Touch $\bigcirc \mathbb{K} \rightarrow [YES] \rightarrow \bigcirc \mathbb{K}$.

Formatting the recording media

Formatting deletes all data from the recording media to recover recordable free space.

Wotes

- · Connect your camcorder to the wall outlet (wall socket) using the supplied AC Adaptor/Charger to prevent your camcorder from running out of power during the operation.
- · To avoid the loss of important images, you should save them (p. 88) before formatting the recording media.
- · Protected movies and still images are also deleted.
- Press the MODE button.
- 2 Touch [MANAGE MEDIA] → [MEDIA FORMAT].
- 3 Touch the recording media to be formatted.
- 4 Touch [YES] \rightarrow [YES] \rightarrow \bigcirc K.

4 Notes

 While [Executing...] is displayed, do not operate the buttons on the camcorder, disconnect the AC Adaptor/Charger, or remove the recording media from your camcorder. (The access lamp is lit or flashing while formatting recording media.)

Preventing data on recording media from being recovered

Unintelligible data will be written on recording media. Thus, it may become more difficult to recover any original data. Even if you format recording media, there may be some data remaining. Therefore, when you dispose of or transfer the recording media, it is recommended that you perform a [A MEDIA EMPTY]/ [← MEDIA EMPTY]/[← MEDIA EMPTY] operation.

4 Notes

- · If you perform this operation, all stored data are deleted. To avoid the loss of important images, they should be saved (p. 88) before the operation.
- · You cannot perform this operation unless you connect the AC Adaptor/Charger to the wall outlet (wall socket).
- · Disconnect all cables except the AC Adaptor/ Charger. Do not disconnect the AC Adaptor/ Charger during the operation.
- · Do not apply any vibrations or shocks to your camcorder during this operation.
- 1 Operate the camcorder on an outside power source using the AC Adaptor/Charger (p. 13).
- 2 Set the POWER switch to ON.
- 3 Press the MODE button.
- 4 Touch [MANAGE MEDIA] → [MEDIA FORMAT].
- 5 Touch the recording media to be formatted.


The format screen appears.

Preventing data on recording media from being recovered (Continued)

6 Press and hold the STOP button for more than 3 seconds.

The media empty screen appears.

STOP button



7 Touch [YES] \rightarrow [YES] \rightarrow \bigcirc K.

4 Notes

- It may take from several minutes to several hours to empty recording media, depending on the capacity. You can check the actual time required on the LCD screen.
- If you stop the operation while [Executing...] appears, be sure to complete the operation by performing [MEDIA FORMAT] or emptying when you use the recording media next time.

Repairing the image database file

This function checks the management information and the consistency of movies and still images on the recording media, and repairs any inconsistencies found.

4 Notes

- Connect your camcorder to the wall outlet (wall socket) using the supplied AC Adaptor/Charger to prevent your camcorder from running out of power during the operation.
- 1 Press the MODE button.
- 2 Touch [MANAGE MEDIA] → [REPAIR IMAGE DB FILE].
- 3 Touch the recording media you want to check the management file.

4 Touch [YES].

The management file check starts.

Touch OK and quit the management file check if no inconsistency is found.

5 Touch [YES].

After [Completed.] appears, touch OK.


4 Notes

 If you stop the operation while [Repairing the Image Database File] appears, be sure to complete the operation as described above when you use the recording media next time.

Operating the menu

You can change various settings or make detailed adjustments using the menu items displayed on the screen.

MENU button



Ϋ Tips

- You may select menu items also with the ◆/◆ buttons.
- Set the POWER switch to ON.
- f 2 Press the MENU button.

The menu screen appears.



3 Turn the SEL/PUSH EXEC dial until the icon of the desired menu is highlighted, then press the dial to select the menu.

CAMERA SET (p. 71)

REC/OUT SET (p. 77)

AUDIO SET (p. 78)

DISPLAY SET (p. 81)

TC/UB SET (p. 85)

OTHERS (p. 86)



4 Turn the SEL/PUSH EXEC dial until the desired menu item is highlighted, then press the dial to select the item.



5 Turn the SEL/PUSH EXEC dial until the desired setting is highlighted, then press the dial to confirm the setting.



Operating the menu (Continued)

6 Press the MENU button to hide the menu screen.

To return to the previous screen, select [♣ RETURN].

Notes

 The available menu items vary depending on the context of your camcorder during recording or playback.

Menu items

•: Functions that return to the default settings when you switch the format, perform the functions by the MODE button, or turn off the camcorder.

(ASSIGN): Functions that can be assigned to the ASSIGN buttons.



(CAMERA SET) menu

,	
(p. 71)	
GAIN SET	
SMOOTH GAIN	
HYPER GAIN	ASSIGN
AGC LIMIT	
MINUS AGC	
IRIS RING ROTATE	ASSIGN
WB PRESET	
WB OUTDOOR	
LEVEL	
WB TEMP SET	
ATW SENS	
SMOOTH WB	
AE SHIFT	ASSIGN
AE RESPONSE	
AUTO IRIS LIMIT	
FLICKER REDUCE	
BACK LIGHT	ASSIGN
SPOTLIGHT	ASSIGN
STEADYSHOT	ASSIGN
AF ASSIST	
FOCUS MACRO	ASSIGN
HANDLE ZOOM	
SPEED ZOOM	
D.EXTENDER	ASSIGN
FADER	ASSIGN
x.v.Color	

🔙 (REC/OUT SET) menu (p. 77)

COLOR BAR

(1 -	,	
	REC SET	
	VIDEO OUT	

(ASSIGN)

(AUDIO SET) menu (p. 78)

r	`	,	٠,	,	,
	AUDIO FOR	MAT			
	AUDIO LIMIT				
	HEADPHONE O	JT			
	INT MIC SET				
	XLR SET				

(DISPLAY SET) menu (p. 8

81)	
ZEBRA	(ASSIGN)
PEAKING	(ASSIGN)
MARKER	(ASSIGN)
EXPANDED FOCUS TYPE	
CAMERA DATA DISPLAY	
AUDIO LEVEL DISPLAY	
ZOOM DISPLAY	
FOCUS DISPLAY	
SHUTTER DISPLAY	
LCD BRIGHT	
LCD COLOR	
LCD BACKLIGHT	
LEVEL	
VF BACKLIGHT	
VF COLOR	
VF POWERMODE	
## REMAINING	
GPS TIME DISPLAY*	

(TC/UB SET) menu (p. 85)

DISPLAY OUTPUT

, (: = , = = .) III (p. 00)
TC PRESET	
UB PRESET	
TC RUN	
TC MAKE	
UB TIME REC	

Menu items (Continued)

(OTHERS) menu (p. 86)

((/
ASSIGN BUTTON	
CLOCK SET	
AREA SET	
SUMMERTIME	
LANGUAGE	
DATE REC	
BEEP	
REC LAMP[F]	ASSIGN
REC LAMP[R]	(ASSIGN)
REMOTE CONTROL	
OPERATION TIME	
CALIBRATION	

SLOW (SMOOTH SLOW REC)

menu (p. 42)

REC MODE **REC TIMING**



(EDIT) menu (p. 58, 59, 61,

62)

PROTECT ADD TO PLAYLIST DIVIDE DELETE DELETE ALL



(PLAYLIST EDIT) menu

(p. 59)

ADD MOVE **ERASE ERASE ALL**

^{*} HXR-NX5E/NX5P only

🛅 (CAMERA SET)

menu

Settings to adjust your camcorder to the recording conditions (GAIN SET/BACK LIGHT/STEADYSHOT, etc.)

The default settings are marked with ▶. The indicators in parentheses appear when the items are selected.

See page 67 for details on selecting menu items.

Press the MENU button → select (CAMERA SET) with the SEL/PUSH EXEC dial.

GAIN SET

You can set gain values for H, M and L positions of the GAIN switch. The default settings of [H], [M] and [L] are 18 dB, 9 dB and 0 dB, respectively.

- ① Select [H], [M] or [L] with the SEL/ PUSH EXEC dial.
- ② Set the gain value with the SEL/PUSH EXEC dial, and press the dial. You can select the value between -6 dB and 21 dB by 3 dB. The larger the value, the higher the gain.
- 3 Select [OK] with the SEL/PUSH EXEC
- (4) Press the MENU button to hide the menu screen.

SMOOTH GAIN

You can set the transition speed at which the gain setting shifts from one value to another, set for the GAIN switch positions, when you switch the GAIN switch from a position to another. You can select the transition speed from [FAST], [MIDDLE] and [SLOW] or set to [OFF]. The default setting is [OFF].

HYPER GAIN

When you set this function to [ON] (HYPER), you can increase the gain to its limit. The default setting is [OFF].

6 Notes

- · During the hyper gain, the picture quality will be reduced due to noise.
- · This function returns to the default setting when you switch the format, perform the function by the MODE button, or turn off the camcorder.
- · When you record a high definition image quality (HD) movie with [HYPER GAIN] set to [ON] and play it with the data code, the gain value is displayed as [---].

Ϋ Tips

- · It is recommended to use this function with manual focus.
- You can assign this function to an ASSIGN button (p. 45).

AGC LIMIT

You can select the upper limit for the Auto Gain Control (AGC) from [OFF] (21 dB, the default setting), [18dB], [15dB], [12dB], [9dB], [6dB], [3dB] and [0dB].

6 Notes

· If you adjust the gain manually, you cannot obtain the effect of [AGC LIMIT].

MINUS AGC

When you set this function to [ON], the automatic gain control range can be expanded to the negative range. Especially in a bright environment, minus gain control allows more suitable gain setting and enables low noise recording. The dynamic range of the camcorder is not reduced when you set [MINUS AGC] to [ON].

Enables minus gain control (up to -3 dB) during automatic gain control, as required.



OFF

Disables minus gain control during automatic gain control.

IRIS RING ROTATE

You can select the operating direction of the iris ring.

► NORMAL

Makes images dark with clockwise rotation of the iris ring.

OPPOSITE

Makes images dark with counterclockwise rotation of the iris ring.

Ϋ́ Tips

 You can assign this function to an ASSIGN button (p. 45).

WB PRESET

You can use the preset white balance. For more details, see page 30.

WB OUTDOOR LEVEL

You can set an offset value to adjust the outdoor white balance when you set [WB PRESET] to [OUTDOOR]. You can select the offset value from [-7] (bluish) -[0](normal) - [+7] (reddish). The default setting is [0].

WB TEMP SET

You can set the color temperature between 2300K and 15000K in 100K steps when you set [WB PRESET] to [MANU WB TEMP].

ATW SENS

You can set the auto white balance operation under a reddish light source such as an incandescent lamp or candle, or under a bluish light source such as in outdoor shade

► INTELLIGENT

Automatically adjusts the white balance so that scenes look natural for the light source

HIGH

Automatically adjusts the white balance while reducing redness or blueness.

MIDDLE

LOW

Automatically adjusts the white balance while increasing redness or blueness.

4 Notes

- · This is only effective when white balance is adjusted automatically.
- · [ATW SENS] is not effective under a clear sky or the sun.

SMOOTH WB

You can set the transition speed at which the color temperature values shifts from one value to another, set for the white balance memory switch positions, when you switch the white balance memory switch from a position to another. You can select the transition speed from [FAST], [MIDDLE] and [SLOW] or set to [OFF]. The default setting is [OFF].

AE SHIFT

ON/OFF

You can turn on or off the function. When [ON] is selected, AS and selected value appear on the screen.

LEVEL

You can set an offset value to adjust the automatic exposure adjustment value from [-7] (dark) - [0] (standard) - [+7] (bright) with the SEL/PUSH EXEC dial. The default setting is [0].

4 Notes

· This function is not effective while you adjust the iris, shutter speed and gain all manually.

· This function is not effective temporarily when [HYPER GAIN] is set to [ON].

Ϋ́ Tips

· You can assign an ASSIGN button to work as [ON/OFF] (p. 45).

AE RESPONSE

You can select the speed at which the exposure is adjusted automatically following the changes in the brightness of the subject. You can select the speed from [FAST], [MIDDLE] and [SLOW]. The default setting is [FAST].

AUTO IRIS LIMIT

You can select the highest iris value for the automatic adjustment from [F11], [F9.6], [F8], [F6.8], [F5.6], [F4.8] and [F4]. The default setting is [F11].

4 Notes

· This function is not effective during the manual iris adjustment.

FLICKER REDUCE

N ON

Reduces flickering. Flickering of the screen under a light source such as fluorescent lamps will be reduced.

0FF

Not reduce flickering.

6 Notes

· Flickering may not be reduced for certain light sources

BACK LIGHT

When you set this function to [ON] (2), you can correct backlighting. The default setting is [OFF].

Wotes

. [BACK LIGHT] is set to [OFF] when you set [SPOTLIGHT] to [ON].

- [BACK LIGHT] is set to [OFF] if all of iris, gain, and shutter speed are adjusted manually.
- · [BACK LIGHT] is set to [OFF] when [HYPER GAIN] is set to [ON].

Ÿ Tips

· You can assign this function to an ASSIGN button (p. 45).

SPOTLIGHT

When you set this function to [ON] (\bigcirc), you can prevent overexposure of light while recording a subject under strong light, such as a stage. For example, you can prevent people's faces from being over-exposed. The default setting is [OFF].

4 Notes

- . [SPOTLIGHT] is set to [OFF] when you set [BACK LIGHT] to [ON].
- . [SPOTLIGHT] is set to [OFF] if all of iris, gain, and shutter speed are adjusted manually.
- . [SPOTLIGHT] is set to [OFF] when [HYPER GAIN] is set to [ON].

Ϋ Tips

· You can assign this function to an ASSIGN button (p. 45).

STEADYSHOT

SET

► STEADYSHOT

You can activate the camera-shake reduction setting.

ACTIVE STEADYSHOT (WACT)

You can use the camera-shake reduction with more powerful effect.

0FF

Select [OFF] (Whore) when you use a tripod (sold separately) to make images look natural.

■ STEADYSHOT TYPE

You can select a type of camera-shake reduction for different recording situations.

HARD

Reduces camera shake considerably. This setting is not suitable for recording when you are using techniques like panning or tilting.

► STANDARD

Standard camera-shake reduction.

SOFT

Reduces camera shakes moderately. Slight unsteadiness remains in movies, which make the movies look as they are.

WIDE CONVERSION

This item is provided for a wide conversion lens (sold separately), and especially effective for Sony wide conversion lens.

■ ACTIVE STEADYSHOT TYPE

You can select a type of powerful camerashake reduction for different recording situations

► STANDARD

Reduces camera shakes more powerfully while you are walking or moving around.

WIDE CONVERSION

This item is provided for using a wide conversion lens (sold separately) in [ACTIVE STEADYSHOT] mode, and especially effective for Sony wide conversion lens.

4 Notes

 At the [ACTIVE STEADYSHOT] setting, the imaging field shifts slightly to the telephoto side, and the resolution will deteriorate slightly, as well.

Ÿ Tips

 You can assign an ASSIGN button to work as [SET] (p. 45).

AF ASSIST

When you set this function to [ON], you can temporarily focus manually using the focus ring during the auto focus adjustment. The default setting is [OFF].

4 Notes

 This function is effective only when the FOCUS switch is set to AUTO (p. 27).

FOCUS MACRO

When you set this function to [ON], you can focus on a subject within 80 cm (about 2 5/8 feet). The default setting is [ON]. When you set this function to [OFF] (**ToFF**), you can set fine focus on a subject further than 80 cm regardless of the zoom position, although you will lose focus on a subject within 80 cm.

Ÿ Tips

 You can assign this function to an ASSIGN button (p. 45).

HANDLE ZOOM

You can select the zoom speed for the FIX position of the handle zoom switch from [1] (slow) through [8] (fast). The default setting is [3].

SPEED ZOOM

When you set this function to [ON], you can increase the zoom speed of the power zoom lever and the handle zoom. The default setting is [OFF].

4 Notes

 When you set this function to [ON], the operation sound of the zoom may also be recorded.

D.EXTENDER

When you set this function to [ON] (DIG.EXT), the displayed image becomes about 1.5 times larger. The image quality decreases because the image is digitally processed. This function helps you to focus on far-away subjects such as a wild bird away at a distance. The default setting is [OFF].

4 Notes

- · The function returns to the default setting when you switch the format, perform the function by the MODE button, or turn off the camcorder.
- You cannot set this function when [HD 720/50p FX]/[HD 720/50p FH] is selected in [REC FORMAT] (p. 25).

ΰ Tips

· You can assign this function to an ASSIGN button (p. 45).

FADER

You can add visual effects to transition between scenes.

- (1) Select [WHITE FADER] or [BLACK FADER] during standby to fade in with the selected effect, or recording to fade out with the selected effect.
- (2) Press the record button. The fader indicator stops flashing and disappears when the fading is complete.

To cancel before starting the operation, select [OFF] in step (1).

The setting will be cleared every time you press the record button.



WHITE FADER







BLACK FADER







6 Notes

- . This function is automatically set to [OFF] (the default setting) when you switch the format, perform the function by the MODE button, or turn off the camcorder.
- · You cannot set [FADER], when different media are selected for the record button and the handle record button in [REC BUTTON SET].
- · You cannot set this function when the remaining space of recording media is less than 1 minute.

Ϋ Tips

· You can assign this function to an ASSIGN button (p. 45).

x.v.Color

When you set this function to [ON] ((COLOR)), you can record with the wider color range. Your camcorder can reproduce brilliant and vivid colors for flowers and the beautiful blue-green of tropical oceans. The default setting is [OFF].

4 Notes

- · The colors may not be well reproduced when you play back a movie recorded with this function set to [ON] on a TV that does not support x.v.Color.
- · You cannot set [x.v.Color] in the following
 - When either memory card or flash memory unit is set to record in standard definition image quality (SD).
 - During recording movies
- When you set [x.v.Color] to [ON], the picture profile will be disabled.

COLOR BAR

ON/OFF

When you select [ON], you can display color bars on the screen or record them on recording media. This function helps you to adjust colors when you view movies recorded with your camcorder on a TV or a monitor. The default setting is [OFF].

4 Notes

- This function is automatically set to [OFF] when you switch the format, perform the function by the MODE button, or turn off the camcorder.
- You cannot change the setting during recording or expanded focus operation, or when fader is set.

■ TYPE

Selects a type of the color bars.



TYPE 1



TYPE 2



TYPE 3



TYPE 4 (75% brightness of TYPE 3)

■ TONE

Outputs audio tone signals (1 kHz: full bit -18 dB) when you set [TONE] to [ON]. The default setting is [OFF].

🍟 Tips

 You can assign an ASSIGN button to work as [ON/OFF] (p. 45).

\Longrightarrow (REC/OUT SET)

menu

Recording settings, input and output settings (REC SET/VIDEO OUT)

The default settings are marked with ▶. The indicators in parentheses appear when the items are selected.

See page 67 for details on selecting menu items.

Press the MENU button → select (REC/OUT SET) with the SEL/PUSH EXEC dial.

REC SET

You can select a recording format.

■ HIDH/HSDH SET See page 24.

REC FORMAT

See page 25.

■ REC BUTTON SET

See page 23.

■ ISDI WIDE REC

You can set the aspect ratio when recording in standard definition image quality (SD).

▶ UN

Records in 16:9.

OFF (4:3)

Records in 4:3. [MARKER] is set to [ON], and [ASPECT] to [4:3] automatically. In the case of [SMOOTH SLOW REC], black bands appear at both sides of the screen.

4 Notes

- · When recording in high definition image quality (HD), the aspect ratio is fixed to 16:9.
- When [FSD] WIDE REC] is set to [OFF], [MARKER] is set to [ON] and the [ASPECT] 4:3 indicator appears automatically. At the same time, when [CENTER], [SAFETY ZONE], or [GUIDEFRAME] is not set to [OFF], a marker is displayed in accordance with the setting. If you do not want to display a marker, set [MARKER] to [OFF] (p. 81).

VIDEO OUT

OUTPUT SELECT

You can select the jack to the output signal.

SDI

► HDMI

COMPONENT

VIDEO

4 Notes

· When you switch the setting between [SDI] and [HDMI], the screen will go out momentarily, and the image and sound will be intermitted.

■ SDI/HDMI/COMPONENT

You can select the resolution of the output signal from the SDI/HDMI/COMPONENT iacks.

720p/576i

► 1080i/576i

576p

576i

DOWN CONVERT TYPE

You can select a down convert type when you down-covert video signal.

Use this function for outputting movies and still images recorded in 16:9.

► SOUEEZE

Outputs a horizontally compressed image while maintaining its original height.

LETTER BOX (16:9)

LETTER BOX (15:9)

LETTER BOX (14:9) LETTER BOX (13:9)

Outputs a vertically compressed image while maintaining its original aspect ratio.

EDGE CROP

Outputs the central portion of the original image by cropping its right and left edges. Press the MENU button → select (REC/OUT SET) with the SEL/PUSH EXEC dial.

4 Notes

- When you view a movie recorded in standard definition image quality (SD) with [SD] WIDE REC] set to [ON] on a standard 4:3 TV, images of the movie may appear horizontally compressed while maintaining its original height. In such a case, select LETTER BOX or [EDGE CROP].
- If you change the setting from [SQUEEZE] to another option, or from another option to [SQUEEZE], the screen will go out momentarily, and the image and sound will be intermitted.

■ SD-SDI SET

VIDEO INDEX

Superimposes the index signal, including aspect ratio and signal system, on the SDI output signal. The default setting is [ON].

► RP188 ATC

Superimposes RP188 ATC (Ancillary Time Code) on the SDI output signal. The default setting is [ON].

VITC LINE SEL

Set the vertical blanking line of the SD video signal to record VITC (Vertical Interval Time Code) between 9 and 22. The default setting is [19].

♪▶(AUDIO SET) menu

Settings for the audio recording (HID) AUDIO FORMAT/XLR SET, etc.)

The default settings are marked with ▶. The indicators in parentheses appear when the items are selected.

See page 67 for details on selecting menu items.

Press the MENU button → select

(AUDIO SET) with the SEL/PUSH

EXEC dial.

IHD: AUDIO FORMAT

You can set the audio format for high definition image quality (HD) recording.

► LINEAR PCM (▷ PCM)

Records in Linear PCM system.

DOLBY DIGITAL (♪DolbvD)

Records in Dolby Digital system.

Notes

 Audio format is fixed to [DOLBY DIGITAL] with the standard definition image quality (SD) recording.

AUDIO LIMIT

You can set the clipping-noise reduction function for CH1/CH2.

▶ OFF

Disables the function.

ON

Enables the function.

4 Notes

 This function is available only when you set the AUTO/MAN (CH1/CH2) switch to MAN.

HEADPHONE OUT

You can set the sound to output to the headphone when the HEADPHONE MONITOR switch is set to STEREO MIX.

► STEREO

Outputs in stereo.

MONO

Outputs in monaural.

INT MIC SET

■ INT MIC SENS

You can set recording sensitivity of the internal microphone.

► NORMAL

Sensitivity that is normally used in professional recordings.

HIGH

Sensitivity that is normally used in consumer recordings.

SENS-Hi appears on the status check screen

■ INT MIC WIND

▶ OFF

Disables wind noise reduction.

UИ

Enables wind noise reduction.

appears on the status check screen.

XLR SET

XLR AGC LINK

You can select either linked or separate AGC (Auto Gain Control) of CH1 and CH2 when using an external microphone.

► SEPARATE

Separately applies the AGC for CH1/CH2. Sound inputs from CH1/CH2 will be recorded as separate sound.

LINKED (\DA_2])

Applies the AGC of CH1 linked with that of CH2. Sound inputs from CH1/CH2 will be recorded as a set of sound such as stereo sound. A appears on the status check screen.

(3 Notes

· This function is available when the CH1 and CH2 switches are set to AUTO and the INPUT1 and INPUT2 switches are both set to MIC or both set to LINE (p. 39).

AUDIO MANUAL GAIN

You can select either linked or separate audio level control of CH1 and CH2 when using an external microphone.

► SEPARATE

Separately controls the audio levels of CH1 and CH2. Sound inputs from CH1 and CH2 will be recorded as separate sound.

LINKED (10 M37)

Controls the audio level of CH1 linked with that of CH2. Sound inputs from CH1 and CH2 will be recorded as a set of sound such as stereo sound. M appears on the status check screen.

4 Notes

- · This function is available when the CH1 and CH2 switches are set to MAN and the INPUT1 and INPUT2 switches are both set to MIC or both set to LINE (p. 39).
- · When you select [LINKED], you can adjust the volume with the AUDIO LEVEL dial of CH1 (p. 39).

■ INPUT1 TRIM

You can adjust the input signal level from INPUT1.

You can select from [-18dB], [-12dB], [-6dB], [0dB], [+6dB] and [+12dB]. The default setting is [0dB].

4 Notes

· The setting is not effective when you set the INPUT1 switch to LINE.

■ INPUT1 WIND

DFF

Disables wind noise reduction.

UИ

Enables wind noise reduction.

appears on the status check screen.

4 Notes

· The setting is not effective when you set the INPUT1 switch to LINE.

■ INPUT2 TRIM

■ INPUT2 WIND

You can set INPUT2 in the same way as INPUT1.

Ϋ́ Tips

- · -48 dBu is set as 0 dB in your camcorder.
- Set INPUT TRIM to [0dB] for the supplied microphone.
- The INPUT TRIM function adjusts the input level from an external microphone. When using a highly sensitive microphone or recording loud sound, set this to the minus side. When using a less sensitive microphone or recording quiet sound, set it to the plus side.
- When recording loud sound, the sound may be distorted at either the input point or the recording point. If it is distorted at the input point, adjust the sound using the INPUT TRIM function. If it is distorted at the recording point, lower the total volume level manually.
- If you set INPUT TRIM too far to the minus side, the microphone volume becomes too low, resulting in a poor signal to noise ratio.
- Test the effect of the [AUDIO SET] function according to the microphone used or the sound field of the recording site before actual recording.

(DISPLAY SET)

menu

Display settings of the display and the viewfinder (MARKER/VF BACKLIGHT/ **DISPLAY OUTPUT, etc.)**

The default settings are marked with ▶. The indicators in parentheses appear when the items are selected.

See page 67 for details on selecting menu items.

Press the MENU button \rightarrow select (DISPLAY SET) with the SEL/PUSH EXEC dial.

ZEBRA

You can display a zebra pattern as a guide for adjusting brightness.

ON/OFF

When you select [ON], and the brightness level appear on the screen. The zebra pattern will not be recorded with the image. The default setting is [OFF].

■ LEVEL

You can select the brightness level between 70 and 100 or 100+. The default setting is [70].

Ϋ́ Tips

- · The zebra pattern is a strip pattern displayed over a part of an image on the screen when the part is higher than the preset brightness level.
- · You can assign an ASSIGN button to work as [ON/OFF] (p. 45).

PEAKING

ON/OFF

When you select [ON], **PEAKING** appears and you can display an image on the screen with its outlines enhanced. This function helps you to adjust the focus. The default setting is [OFF].

■ COLOR

You can select peaking color from [WHITE], [RED] and [YELLOW]. The default setting is [WHITE].

■ LEVEL

You can select a peaking sensitivity from [HIGH], [MIDDLE] and [LOW]. The default setting is [MIDDLE].

4 Notes

· The enhanced outlines will not be recorded on the recording media.

aqiT 🌣

- · You can focus more easily using this function in combination with the expanded focus function
- · You can assign an ASSIGN button to work as [ON/OFF] (p. 45).

MARKER

ON/OFF

When you select [ON], you can display markers. The default setting is [OFF]. Markers will not be recorded on the recording media.

CENTER

When you select [ON], you can display a marker at the center of the screen. The default setting is [ON].



ASPECT

You can display markers at boundaries of display area defined by the aspect ratio, which you can select from [4:3], [13:9], [14:9], and [15:9]. The default setting is [OFF].



SAFETY ZONE

When you select either one of [80% (16:9)], [80% (4:3)], [90% (16:9)] or [90% (4:3)], you can display markers at boundaries of

display area that regular home TVs can display. The default setting is [OFF].



■ GUIDEFRAME

When you select [16:9] or [4:3], you can display frame markers that help you to check horizontal and vertical positions of a subject. The default setting is [OFF].



4 Notes

- Only the time code is output to an external device via external output jacks when [MARKER] is set to [ON], even if [DISPLAY OUTPUT] is set to [ALL OUTPUT].
- You cannot display markers under following conditions:
 - [EXPANDED FOCUS]
 - During [SMOOTH SLOW REC]
 - When the current time is displayed after the power is turned on
- You can display markers only on the LCD panel and viewfinder. You cannot display them on an external device.

Ϋ́ Tips

- You can display all types of markers at the same time.
- You can obtain a balanced composition by positioning the subject at the cross points of the guideframe marker.
- You can assign an ASSIGN button to work as [ON/OFF] (p. 45).

EXPANDED FOCUS TYPE

You can set a type of the expanded focus display.

► TYPE 1


Simply enlarges images.

TYPE 2

Enlarges and shows images in black and white.

CAMERA DATA DISPLAY

When you set this function to [ON], you can constantly display the iris, gain and shutter speed settings on the screen. The default setting is [OFF].




Ϋ́ Tips

- The settings appear on the screen during the manual adjustment regardless of the settings of this function.
- A indicates that the settings are automatically adjusted values.
- The displayed settings are different from the settings that will be displayed when you press the DATA CODE button (p. 51).

AUDIO LEVEL DISPLAY

When you set this function to [ON], you can display the audio level meter on the screen. The default setting is [ON].



ZOOM DISPLAY

▶ BAR

Displays a bar that indicates the zoom position.

NUMBER

Displays a number (0 through 99) that indicates the zoom position.

FOCUS DISPLAY

You can select how to display the focal distance during manual focus.

► METER

Displays the focal distance in meters.

FEET

Displays the focal distance in feet.

SHUTTER DISPLAY

You can select how to display the shutter speed.

▶ SECOND

Displays the shutter speed in seconds.

DEGREE

Displays the shutter speed in degrees. The shutter speed equal to the period that your camcorder reads image data from the image sensor is defined as 360 degrees. The degree is calculated based on this definition and displayed.

- When [REC FORMAT] is set to the followings, 1/50 second is defined as 360 degrees.
 - HD 1080/50i FX SD 576/50i HQ
 - HD 1080/50i FH SD 576/50i HO
 - HD 1080/50i HQ SD 576/50i HQ
 - HD 1080/50i LP SD 576/50i HQ
 - HD 720/50p FX SD 576/50i HQ
- HD 720/50p FH SD 576/50i HQ
- When [REC FORMAT] is set to the followings, 1/25 second is defined as 360 degrees.
- HD 1080/25p FX SD 576/25pSCAN HO HD 1080/25p FH SD 576/25pSCAN HQ

For details on [REC FORMAT], see page 25

4 Notes

· When you press the DATA CODE button, the shutter speed will be displayed in seconds regardless of the setting of this function.

Ϋ́ Tips

• Shutter speed slower than 360° are displayed in multiples of 360° , such as $360^{\circ} \times 2$.

LCD BRIGHT

You can adjust the brightness of the LCD screen. Changes in the LCD brightness will not affect the brightness of recording images.

Ÿ Tips

• You can also turn off the LCD backlight (p. 15).

LCD COLOR

You can adjust the color level of the LCD panel. Changes in the LCD color level will not affect the color level of recording images.

LCD BACKLIGHT LEVEL

You can adjust the backlight level of the LCD screen.

NORMAL

Standard brightness.

BRIGHT

Brightens the LCD screen.

4 Notes

- · When you connect your camcorder to outside power sources, [BRIGHT] is automatically selected for the setting.
- When you select [BRIGHT], the recordable time with the battery is slightly reduced.

VF BACKLIGHT

You can adjust the brightness of the viewfinder.

► NORMAL

Standard brightness.

BRIGHT

Brightens the viewfinder screen.

4 Notes

- When you connect your camcorder to outside power sources, [BRIGHT] is automatically selected for the setting.
- When you select [BRIGHT], the recordable time with the battery is slightly reduced.

VF COLOR

ON

Displays images in the viewfinder in color.

0FF

Displays images in the viewfinder in black and white.

VF POWERMODE

► AUTO

Turns on the viewfinder while you close the LCD panel or record in mirror mode.

ON

Always turns on the viewfinder.

■ REMAINING

AUTO

Displays the remaining recording time available for movies when you re-enter movie recording mode or switch to [SMOOTH SLOW REC]. When the remaining time is 5 minutes or more, the display goes off after 8 seconds.

► ON

Always displays the remaining recording time available for movies.

GPS TIME DISPLAY (HXR-NX5E/NX5P)

You can select the GPS time as the data code.

► LOCAL TIME

Displays the time with the time difference compensated for. The local time with the summer time setting taken into account is displayed.

UTC TIME

Displays the coordinated universal time.

Wotes

 In the case of still images, if you select [LOCAL TIME], the triangulated time is displayed as [-----].

DISPLAY OUTPUT

You can select where to output the display information, such as time code.

► LCD PANEL

Outputs the information to the LCD screen and viewfinder.

ALL OUTPUT

Outputs the information to the LCD screen, viewfinder, SDI output, HDMI output, component output and video output.

4 Notes

 Only the time code is output when [MARKER] is set to [ON] and a marker is displayed on the screen.

(TC/UB SET) menu

(TC PRESET/UB PRESET, etc.)

The default settings are marked with ▶. The indicators in parentheses appear when the items are selected.

See page 67 for details on selecting menu items.

Press the MENU button → select (TC/UB SET) with the SEL/PUSH EXEC dial.

TC PRESET

See page 43.

UB PRESET

See page 43.

TC RUN

You can select how the time code advances.

► REC RUN

Advances the time code only during recording.

Select this setting to record the time code continuous from the last time code of the previous recording.

FREE RUN

Advances the time code regardless of operation of your camcorder.

4 Notes

- Even if the time code advances in the [REC RUN] mode, the time code may not be recorded sequentially in the following cases:
 - When the recording format is changed.
 - When the images are recorded on the memory card and the flash memory unit simultaneously.
 - When the recording media is removed.

TC MAKE

▶ PRESET

Records the newly set time code on the recording media.

REGENERATE

Reads the last time code of the previous recording from the recording media and records the new time code consecutively from the last time code during the backspace editing.

The time code runs in [REC RUN] mode regardless of the setting of [TC RUN].

UB TIME REC

► OFF

Does not save the actual time in the user bit code.

ON

Saves the actual time in the user bit code.

6 Notes

• The last 2 digits are fixed to 00 when it is set to [ON].

(OTHERS) menu

Settings while recording or other basic settings (AREA SET/BEEP, etc.)

The default settings are marked with ▶. The indicators in parentheses appear when the items are selected.

See page 67 for details on selecting menu items.

Press the MENU button → select (OTHERS) with the SEL/PUSH EXEC dial.

ASSIGN BUTTON

See page 45.

CLOCK SET

See page 17.

AREA SET

You can adjust a time difference without stopping the clock. When you use your camcorder abroad, you can adjust the clock to the local time.

SUMMERTIME

You can change this setting without stopping the clock. Set to [ON] to move the time forward I hour.

▶ 0FF

Does not set the summertime.

ON

Sets the summertime.

LANGUAGE

You can select the language to be used on the LCD screen.

Ϋ Tips

 Your camcorder offers [ENG[SIMP]] (simplified English) in case that you cannot find your native tongue among the options.

DATE REC

► OFF

Does not superimpose the date and time on images.

ON

Superimposes the date and time on images.

ż Tips

 When zebra or peaking is activated, the date and time characters are affected by the signal, but properly recorded on images.

BEEP

DFF

Cancels the melody.

ON

Activates a melody when you start/stop recording, or when you are warned with warning indicators, etc.

REC LAMP[F] (Recording lamp [front])

When you set this function to [OFF], you can turn off the front camera recording lamp. The default setting is [ON].

Ϋ́ Tips

 You can assign this function to an ASSIGN button (p. 45).

REC LAMP[R] (Recording lamp [rear])

When you set this function to [OFF], you can turn off the rear camera recording lamp. The default setting is [ON].

Ÿ Tips

 You can assign this function to an ASSIGN button (p. 45).

REMOTE CONTROL

When you set this function to [ON], you can use the supplied Wireless Remote Commander (p. 121). The default setting is [ON].

🍟 Tips

 Set to [OFF] to prevent your camcorder from responding to a command sent by another remote control unit.

OPERATION TIME

Displays the total hours of operation in 10-hour increments.

CALIBRATION

See page 110.

Saving images with a computer

Preparing a computer (Windows)

You can perform following operations using "Content Management Utility."

- · Importing images to a computer
- · Viewing imported images

To save movies using a computer, install the software from the supplied CD-ROM "Content Management Utility" beforehand. Use commercially available software to edit images or create discs.

Step 1 Checking the computer system

0S*1

Microsoft Windows XP SP3*2/Windows Vista SP2*3/Windows 7

CPU

Use an Intel Core 2 Duo 2.20 GHz CPU or faster to play back videos with high definition image quality (HD) in the FX mode.

Videos with high definition image quality (HD) recorded in other than the FX mode may be played back with a slower CPU. Depending on the performance of your video card, videos with high definition image quality (HD) recorded using the FX mode may be played back with a slower CPU than that recommended above.

For the following operations, an Intel Pentium III 1GHz or faster is necessary.

- Importing movies to the computer
- Processing with standard definition image quality (SD)

Memory

For Windows XP: 512 MB or more (1 GB or more is recommended.) However, 256 MB or more is sufficient for processing only the movies with standard definition image quality (SD).

For Windows Vista/Windows 7: 1 GB or more

Hard disk

Disk volume required for installation: Approximately 100 MB Only the NTFS or exFAT file system can be

Only the NTFS or exFAT file system can be used for importing videos or registering them for viewing.

Display

Minimum 1.024×768 dots

Others

USB port (this must be provided as standard, High-Speed USB (USB 2.0 compatible)) (CD-ROM drive is necessary for installation)

- *1 Standard installation is required. Operation is not assured if the OS has been upgraded or in a multi-boot environment.
- *2 64-bit editions and Starter (Edition) are not supported.
- *3 Starter (Edition) is not supported.

6 Notes

- Operation with all computer environments is not assured.
- The supplied software "Content Management Utility" is not supported by Macintosh computers.

Step 2 Installing the supplied software "Content Management Utility"

Install "Content Management Utility" before connecting your camcorder to a computer.


- ① Confirm that your camcorder is not connected to the computer.
- ② Turn on the computer.
 - · Log on as an Administrator for installation.
 - Close all applications running on the computer before installing the software.
- ③ Place the supplied CD-ROM "Content Management Utility" in the disc drive of your computer.

The installation screen appears.

- If the screen does not appear, click [Start]
 - → [Computer] (in Windows XP, [My

Computer]), then double-click [SONYCMU(E:)] (CD-ROM).

- 4 Select the language for the application to be installed, then click [OK].
- (5) When the install wizard screen appears, click [Next].
- 6 Confirm the license agreement, and if you accept the terms, click [Next].
- (7) Select the drive or folder to install the application, then click [Next].
- Select the option to create the desk-top shortcut, then click [Next].
- (9) Turn on your camcorder, then connect the camcorder to the computer using the supplied USB cable.



The [USB SELECT] screen appears on the camcorder screen automatically.

- ① Touch [₹A] or [₹B] on the camcorder screen.
 - If the [USB SELECT] screen does not appear, press the MODE button, then touch [MANAGE MEDIA] → [USB CONNECT].
- ① Click [Next].
- ② Follow the on-screen instructions to install the software.
 - Restart the computer if required to complete the installation.

When the installation is completed, the following icon will appear, depending on the selection in step (a).



(3) Remove the CD-ROM from the computer.

To disconnect your camcorder from the computer

 Click the to icon at the bottom right of the desktop of the computer → [Safely remove USB Mass Storage Device-Drive].



- ② Touch [END] → [YES] on the camcorder screen.
- 3 Disconnect the USB cable.

Troubleshooting

If you run into any problems using your camcorder, follow the flow chart below.

① Check your camcorder, referring to the items on pages 90 to 98.



② Disconnect the power source, reconnect the power source after about 1 minute and turn on your camcorder.



③ Press the RESET button (p. 120) with a pointed object, then turn on your camcorder. This operation will reset the date, time and area settings.



- 4 Consult your Sony dealer or local authorized Sony service facility.
- Power sources/LCD screen/Wireless Remote Commander...p. 90
- Memory card/flash memory unit...p. 92
- Recording...p. 92
- Playback---p. 95
- Connecting to TV---p. 96
- Dubbing/Editing/Connecting to other devices...p. 97
- GPS (HXR-NX5E/NX5P)...p. 97
- Connecting to a computer ... p. 98

Power sources/LCD screen/Wireless Remote Commander

The power does not turn on or abruptly turns off.

- Attach a charged battery pack to the camcorder (p. 12).
- Use the AC Adaptor/Charger to connect to a wall outlet (wall socket) (p. 12).

The camcorder does not operate even when the power is set to on.

- Disconnect the AC Adaptor/Charger from the wall outlet (wall socket) or remove the battery pack, then reconnect it after about 1 minute.
- Press the RESET button (p. 120) using a sharp-pointed object.

The camcorder gets warm.

• The camcorder may get warmer while you use it. This is not a malfunction.

The remaining battery time indicator does not indicate the correct time.

- Ambient temperature is too high or too low, or the battery pack has not been charged enough.
 This is not a malfunction.
- Fully charge the battery again. If the problem persists, the battery may be worn-out. Replace it with a new one (p. 12, 107).
- The indicated time may not be correct in certain circumstances. For example, when you open
 or close the LCD panel, it takes about 1 minute to display the correct remaining battery time.

The battery pack discharges too quickly.

- Ambient temperature is too high or low, or the battery pack has not been charged enough. This is not a malfunction.
- Fully charge the battery again. If the problem persists, the battery may be worn-out. Replace it with a new one (p. 12, 107).

The image remains on the LCD screen.

• This occurs if you disconnect the DK-415 cable or remove the battery pack without turning off the power first. This is not a malfunction.

The image in the viewfinder is not clear.

• Move the viewfinder lens adjustment lever until the image appears clearly (p. 16).

The image in the viewfinder has disappeared.

• If you set [VF POWERMODE] to [AUTO], the finder light remains off while the LCD panel is open (p. 84).

The supplied Wireless Remote Commander does not function.

- Set [REMOTE CONTROL] to [ON] (p. 87).
- Remove any obstructions between the Wireless Remote Commander and the remote sensor of the camcorder
- Keep strong light sources, such as sunlight or overhead lighting, away from the remote sensor, otherwise the Wireless Remote Commander may not function properly.
- Insert a fresh battery in the compartment with its +/- terminals matching those of the compartment (p. 121).

Another video device malfunctions when you use the supplied Wireless Remote Commander.

- Select a commander mode other than DVD2 for your video device.
- Cover the sensor of your video device with black paper.

When a device is connected to the REMOTE jack, the camcorder or the device does not operate properly.

- The connected device may react slowly to some operations, such as zooming.
- If you disconnect the cable from the device while the cable is still connected to the camcorder's REMOTE jack, the camcorder may not restore the proper settings. Disconnect the cable also from the camcorder's REMOTE jack.

Memory card/flash memory unit

The remaining movie recording indicator is not displayed.

• Set [REMAINING] to [ON] to always display the remaining movie recording indicator (p. 84).

The camcorder does not operate with the memory card inserted.

• The memory card was formatted on a computer. Format it on this camcorder (p. 65).

The data file name is incorrect, or flashing.

- · The file is damaged.
- Use a file format supported by your camcorder (p. 104).

The recording media indicator is flashing.

 Something wrong happened to one of recording media. Stop recording of all recording media, and repair the database file.

Images on the recording media cannot be deleted.

- You can select no more than 100 images to be deleted on the edit screen.
- The images are protected. Release the protect function (p. 58).

Recording

The recording does not start when you press the record button.

- The playback screen is displayed. Finish playback operation (p. 47).
- There is no empty space on the recording media. Replace the recording media with new one, delete unnecessary images (p. 62) or format the recording media (p. 65).
- Total number of movie scenes exceeds the recordable capacity of your camcorder (p. 102).
 Delete unnecessary images (p. 62).
- The temperature of your camcorder is extremely high. Turn off your camcorder and leave it for a while in a cool place.
- The temperature of your camcorder is extremely low. Turn off your camcorder and leave it for a while in a warm place.
- A particular record button is selected to start/stop recording. Check the record button setting (p. 23).
- Something wrong happened to one of recording media. Stop recording of all recording media, and repair the database file.

The handle zoom does not work.

• Set the handle zoom switch to FIX or VAR (p. 26).

The access lamp remains lit even after recording was stopped.

• Your camcorder is recording the scene you have just shot on the memory card.

The imaging field looks different.

• The imaging field may look different depending on the condition of your camcorder. This is not a malfunction.

The actual recording time for movies is less than the expected recording time of the recording media.

• Depending on the recording conditions, the time available for recording may be shorter, for example when recording a fast moving object, etc. (p. 101).

The camcorder does not keep the setting changes.

- Some menu items return to the default setting when the power is turned off (p. 69).
- The LCD backlight setting and the EXPANDED FOCUS setting are not stored.
- You disconnected the power sources when the POWER switch was set to ON. Before disconnecting the battery or the AC Adaptor/Charger, set the POWER switch to OFF and make sure that the access lamp is turned off.

There is a time difference between the point when the record button is pressed and the point that the recording movie is started or stopped actually.

• On your camcorder, there may be a slight time difference between the point where you press the record button and the actual point that recording movie starts/stops. This is not a malfunction.

There are time differences in recording start/stop points of the simultaneously recorded movies.

• When you do the simultaneous recording with [HD]/[SD] SET] set to []: HD] EXT: SDE] or [: SDE | EXT: HDE], there may be slight time lags in the recorded movies. This is not a malfunction

The aspect ratio (16:9 (wide)/4:3) cannot be changed.

• The aspect ratio of high definition image quality (HD) movies is 16:9 (wide).

Automatic focus does not function.

- Set the FOCUS switch to AUTO to enable the automatic focus function (p. 27).
- Adjust the focus manually if the automatic focus does not work properly (p. 27).

[This function is currently not available.] appears when selecting a function on the MODE menu.

- Try again after finishing all tasks currently selected on the MODE menu.
- If 720 is selected as [REC FORMAT] for [SMOOTH SLOW REC], select 1080 as [REC FORMAT].

Menu items are grayed out or do not work.

• You cannot select grayed out display items in the current recording/playback situation.

Troubleshooting (Continued)

 There are some functions you cannot activate simultaneously. The following list shows examples of unworkable combinations of functions and menu items.

Cannot use	Situation
[BACK LIGHT], [SPOTLIGHT], [ON/ OFF] of [AE SHIFT]	All of iris, gain, and shutter speed are set manually. [HYPER GAIN] is set to [ON].
[FADER]	The record button and the handle record button are set to different recording media. The camcorder is unable to record images. The recording media has less than 1 minute of remaining capacity. [COLOR BAR] is set to [ON].
[ZEBRA], [PEAKING], [CAMERA DATA DISPLAY]	[COLOR BAR] is set to [ON].
[ON/OFF] of [MARKER]	[EXPANDED FOCUS] is set to [ON]. While the date and time are displayed when the power is turned on.
[LCD BACKLIGHT LEVEL], [VF BACKLIGHT]	AC power source is being used.
[TC PRESET]	[TC MAKE] is set to [REGENERATE]. When inputting time code, [TC RUN] is set to [FREE RUN] and [TC MAKE] is set to [PRESET].
[UB TIME REC]	Date and time are not set.
[AREA SET], [DATE REC], [SUMMERTIME]	Date and time are not set.
[x.v.Color]	[HD:/SSET] is set to [HD-SD] or [SD-HD].
[COLOR BAR]	Movies are being recorded. [FADER] is selected. [EXPANDED FOCUS] is set to [ON].
[D.EXTENDER]	[REC FORMAT] is set to [HD 720/50p FX] or [HD 720/50p FH].

Iris, gain, shutter speed, or white balance cannot be adjusted manually.

• Set the AUTO/MANUAL switch to MANUAL.

Tiny spots in white, red, blue, or green appear on the screen.

• This phenomenon appears when using a slow shutter speed (p. 29). This is not a malfunction.

The subjects passing by the frame very fast appear crooked.

• This is called the focal plane phenomenon. This is not a malfunction. Because of the way that the image device (CMOS sensor) reads out image signals, the subjects passing by the frame rapidly might appear crooked depending on the recording conditions.

The LCD screen is too bright, and the subject cannot be seen.

- · Set [BACK LIGHT] to [OFF].
- Set [HYPER GAIN] to [OFF].

The LCD screen is too dark, and the subject cannot be seen.

• Press and hold the DISPLAY button for a few seconds to turn on the backlight (p. 15).

Horizontal stripes appear on the image.

• This occurs when recording pictures under a fluorescent lamp, sodium lamp, or mercury lamp. This is not a malfunction. This can be improved by changing the shutter speed (p. 29).

The image appears divided horizontally.

• This occurs when you light the subject using a flash. This can be avoided by using a shutter speed as slow as possible (p. 29).

Black bands appear when you record a TV screen or computer screen.

• This can be improved by adjusting the shutter speed (p. 29).

Fine patterns flicker, diagonal lines look jagged.

• Adjust [DETAIL] to the negative side (p. 37).

The time code is not recorded in sequence.

• The time code may not be recorded sequentially if you change the settings of [HID]/HSDR SET] and [REC FORMAT].

Plavback

Refer also to the "Memory card/flash memory unit" section (p. 92).

The desired images cannot be found. Images cannot be played back.

- · Select the recording media and image quality of the image you want to play back on the VISUAL INDEX screen (p. 47).
- Image data cannot be played back if you have modified file names or folders, or have edited the data on a computer (When viewing still images, the file name flashes). This is not a malfunction (p. 107).
- Images recorded on other devices may not be played back, or displayed in incorrect size. This is not a malfunction.

Troubleshooting (Continued)

The data file name is displayed incorrectly, or flashing.

- The file is damaged.
- The file format is not supported on your camcorder (p. 104).
- Only the file name is displayed, if the folder structure does not conform to the universal standard.

No sound or only a low sound is heard.

- Turn up the volume (p. 49).
- Movies recorded using [SMOOTH SLOW REC] do not have sounds.

"---" is displayed on the screen.

- The recording media you are playing was recorded without setting the date and time.
- The recording media you are playing was recorded with [HYPER GAIN] set to [ON].
- Bars will be displayed for the camera data of the movies recorded with [SMOOTH SLOW REC] or [COLOR BAR] set to [ON].
- Bars will be displayed for the exposure correction value and flash information of the still images created with [PHOTO CAPTURE].

Multi ch appears on the LCD screen.

 This appears when you play back movies recorded with 5.1ch surround sound. 5.1ch surround sound is down-mixed to 2ch stereo and played back on your camcorder.

Connecting to TV

Neither image nor sound is played back on the TV connected with the component video cable.

- Set [VIDEO OUT] according to the requirements of the connected device (p. 77).
- When you are using the component video cable, make sure that you connect the red and white plugs of the A/V connecting cable (p. 54).

Neither image nor sound is played back on the TV connected with the HDMI cable.

 Images are not output from the HDMI OUT jack, if copyright protection signals are recorded in the images.

Neither image nor sound is played back on the TV, projector, or AV amplifier connected with the HDMI cable.

 If you cannot view images or hear sound on the TV, projector, or AV amplifier connected with the HDMI cable, try disconnecting and connecting the HDMI cable, or turn on your camcorder again.

Neither image nor sound is played back on the TV or monitor connected with the HDMI cable or a commercially available 75 Ω (ohm) coaxial cable.

• Signals are not output from the HDMI OUT and SDI OUT jacks when the USB jack is connected.

The image appears distorted on the 4:3 TV.

• This happens when viewing a movie recorded in 16:9 (wide) mode on a 4:3 TV. Select [REC/ OUT SET] \rightarrow [VIDEO OUT] \rightarrow [DOWN CONVERT TYPE] \rightarrow the appropriate down conversion type (p. 77).

Black zone appears at top and bottom of a 4:3 TV screen.

• This happens when viewing a movie recorded in the 16:9 (wide) mode on a 4:3 TV. This is not a malfunction.

Dubbing/Editing/Connecting to other devices

Time code and other information appear on the display of the connected device.

• Set [DISPLAY OUTPUT] to [LCD PANEL] while connected with the A/V connecting cable (p. 84).

Dubbing cannot be done correctly using the A/V connecting cable.

• The A/V connecting cable is not connected properly. Make sure that the A/V connecting cable is connected to the input jack of the other device for dubbing images from your camcorder

Sound cannot be added to the recording media after recording.

You cannot add sound to the recording media after recording on your camcorder.

Dubbing cannot be done correctly using the HDMI cable.

· You cannot dub movies using the HDMI cable.

GPS (HXR-NX5E/NX5P)

The camcorder is not receiving a GPS signal.

• Your camcorder may not be able to receive radio signals from GPS satellites because of obstructions. Bring your camcorder to an open area. For details on places where radio signals do not reach, see page 105.

The triangulating location is different from the actual current location.

• If your camcorder receives the radio signal reflected by surrounding buildings, or weak radio signals, the margin of error can be as wide as several-hundred meters, at a maximum.

Troubleshooting (Continued)

Connecting to a computer

The computer does not recognize the camcorder.

- Disconnect the cable from the computer, then connect it again securely.
- Disconnect the cable from the computer, restart the computer, then connect the computer to your camcorder correctly.

Movies cannot be viewed or copied to a computer.

- Disconnect the cable from the computer, then connect it again.
- You need to install the supplied "Content Management Utility" to copy movies from your camcorder to your computer (p. 88).

The computer freezes.

 Disconnect the cable from your computer and camcorder. Reboot your computer, and connect your computer and camcorder following the steps in the correct order (p. 88).

Warning indicators and messages

Self-diagnosis display/Warning indicators

When an error occurs, a warning indicator appears on the LCD screen or in the viewfinder.

You can fix some problems associated with the symptoms yourself. If the problem persists even after you have tried a couple of times, contact your Sony dealer or local authorized Sony service facility.

C:04:□□

· The battery pack is not an "InfoLITHIUM" battery pack. Use an "InfoLITHIUM" battery pack (p. 107).

C:06:□□

• The battery pack is too hot. Replace the battery pack, or remove it and put it in a cool place.

C:13:□□

• Remove the recording media. After installing them again, operate your camcorder.

C:32:□□

• Remove the power source. Reconnect it and operate your camcorder again.

E:20:□□ / E:61:□□ / E:62:□□ / E:92:□□ / E:94:□□ / E:95:□□

• Try the steps 2 to 4 on page 90.

(Battery level warning)

- · The battery pack is nearly used up.
- · Depending on the operating. environment, or battery conditions, may flash, even if there are approximately 5 to 10 minutes remaining.

▲ [] (Warning indicator pertaining to battery pack temperature)

• The battery pack is too hot. Replace the battery pack, or remove it and put it in a cool place.

pertaining to memory cards)

Slow flashing

- · Free spaces for recording images are running out. For the type of memory cards you can use with your camcorder, see page 2.
- No memory card is inserted (p. 19).

Fast flashing

- · There are not enough free spaces for recording images. Delete unnecessary images (p. 62), or format the memory card (p. 65) after storing the images on other media (p. 88).
- · The image database file may be damaged (p. 66).

র্মিন র্ম'B (Warning indicators pertaining to memory card formatting)

- · The memory card is damaged.
- · The memory card is not formatted correctly (p. 65).

€ (Warning indicator pertaining to incompatible memory cards)

· Incompatible memory card is inserted (p. 2).

€A ⊶ €B ⊶ (Warning indicator pertaining to the write-protect of the memory card)

· Access to the memory card was restricted on another device.

Warning indicators and messages (Continued)

☐EXT (Warning indicator pertaining to a flash memory unit)

Slow flashing

- Free spaces for recording images are running out. For the flash memory unit you can use with your camcorder, see page 20.
- No flash memory unit is attached (p. 20).

Fast flashing

- There are not enough free spaces for recording images. delete unnecessary images (p. 62), or format the flash memory unit (p. 65) after storing the images on other media (p. 88).
- The image database file may be damaged (p. 66).

- · The flash memory unit is damaged.
- The flash memory unit is not formatted correctly (p. 65).
- * When [BEEP] is set to [ON] (p. 86), you hear a melody when the warning indicators appear on the screen.

Warning messages

If messages appear on the screen, follow the instructions.

Recording time of movies

Estimated time of recording and playback with each battery pack

Recording time

Approximate time available when you use a fully charged battery pack.

(unit: minute)

Battery pack	Continuous recording time	Typical recording time
NP-F570	110	65
	120	70
NP-F770	245	135
	255	140
NP-F970	370	205
	385	215

Wotes

 Top: HXR-NX5E/NX5P Bottom: HXR-NX5M

Using ECM-XM1

- · Typical recording time shows the time when you repeat recording start/stop, zooming, and so on.
- · Times measured when using the camcorder at 25 °C (77 °F) (10 °C to 30 °C (50 °F to 86 °F) is recommended).
- The recording and playback time will be shorter when you use your camcorder in low temperatures.
- The recording and playback time will be shorter depending on the conditions under which you use your camcorder.

Playing time

Approximate time available when you use a fully charged battery pack.

(unit: minute)

Battery pack	HXR-NX5E/ NX5P	HXR-NX5M
NP-F570	170	180
NP-F770	355	375
NP-F970	530	570

4 Notes

· Playing on the LCD screen with the LCD backlight turned on

Estimated recording time of movies

High definition image quality (HD)

■ When [HID] AUDIO FORMAT] is set to [LINEAR PCM]

(unit: minute)

	AVCHD 24 M (FX)	AVCHD 17 M (FH)	AVCHD 9 M (HQ)	AVCHD 5 M (LP)
1 GB	4	6	10	15
	(4)	(6)	(8)	(10)
2 GB	10	10	20	35
	(10)	(10)	(15)	(30)
4 GB	20	25	45	70
	(20)	(25)	(35)	(60)
8 GB	40	55	95	150
	(40)	(55)	(70)	(130)
16 GB	85	110	190	300
	(85)	(110)	(145)	(260)
32 GB	170	225	385	605
	(170)	(225)	(295)	(525)

(unit: minute)

	AVCHD 24 M (FX)	AVCHD 17 M (FH)	AVCHD 9 M (HQ)	AVCHD 5 M (LP)
1 GB	5	6	10	20
	(5)	(6)	(9)	(15)
2 GB	10	10	25	40
	(10)	(10)	(15)	(35)
4 GB	20	25	50	90
	(20)	(25)	(40)	(75)
8 GB	45	55	105	185
	(45)	(55)	(80)	(155)
16 GB	90	115	215	375
	(90)	(115)	(165)	(315)
32 GB	180	235	435	750
	(180)	(235)	(335)	(630)

Standard definition image quality (SD)

(unit: minute)

	SD 9 M (HQ)	
1 GB	10 (10)	
2 GB	25 (25)	
4 GB	55 (50)	
8 GB	115 (105)	
16 GB	235 (210)	
32 GB	475 (425)	

Notes

- The recordable time may vary depending on the recording and subject conditions, [REC SET] (p. 77).
- The number in () is the minimum recordable time.

Ϋ́ Tips

- You can record movies of a maximum of 3,999 scenes with high definition image quality (HD), and 9,999 scenes with standard definition image quality (SD).
- The maximum continuous recording time of movies is approximately 13 hours.

- Your camcorder uses the VBR (Variable Bit Rate) format to automatically adjust image quality to suit the recording scene. This technology causes fluctuations in the recording time of the media. Movies containing quickly moving and complex images are recorded at a higher bit-rate, and this reduces the overall recording time.
- Bit-rate (movie + audio, etc.), number of pixels, and aspect ratio of each recording mode of movies are as follows.
 - High definition image quality (HD)
 FX: max. 24 Mbps 1920 × 1080/16:9,
 1280 × 720/16:9
 FH: approx. 17 Mbps (ave.) 1920 × 1080/
 16:9, 1280 × 720/16:9
 HQ: approx. 9 Mbps (ave.) 1440 × 1080/16:9
 LP: approx. 5 Mbps (ave.) 1440 × 1080/16:9
 - Standard definition image quality (SD)
 HQ: approx. 9 Mbps (ave.) 720 × 576/16:9,
- Number of pixels and aspect ratio of still images (Still images are created from movies.)
 1920 x 1080 dots/16:9
 640 x 480 dots/16:9
 640 x 480 dots/4:3

Using your camcorder abroad

Power supply

You can use your camcorder in any country/region using the AC Adaptor/ Charger supplied with your camcorder within the AC 100 V to 240 V, 50 Hz/ 60 Hz range.

Viewing high definition image quality (HD) movies

In countries/regions where 1080/50i is supported, you can view the movies with the same high definition image quality (HD) as that of the recorded movies. You need a PAL-system-based and 1080/50i compatible TV (or monitor) with component and AUDIO/VIDEO input jacks. The component video cable (supplied) or an HDMI cable (sold separately) must be connected.

Viewing standard definition image quality (SD) movies

To view standard definition image quality (SD) movies, you need a PAL-system-based TV with AUDIO/VIDEO input jacks. An A/V connecting cable must be connected.

On TV color systems

Your camcorder is PAL system, so its picture can only be viewed on a PAL-system TV with AUDIO/VIDEO input jacks.

System	Used in
PAL	Australia, Austria, Belgium,
	China, Czech Republic,
	Denmark, Finland, Germany,
	Holland, Hong Kong, Hungary,
	Italy, Kuwait, Malaysia,
	New Zealand, Norway, Poland,
	Portugal, Singapore,
	Slovak Republic, Spain,
	Sweden, Switzerland, Thailand,
	United Kingdom, etc.
PAL - M	Brazil


System	Used in
PAL - N	Argentina, Paraguay, Uruguay.
SECAM	Bulgaria, France, Guiana, Iran, Iraq, Monaco, Russia, Ukraine, etc.
NTSC	Bahama Islands, Bolivia, Canada, Central America, Chile, Colombia, Ecuador, Guyana, Jamaica, Japan, Korea, Mexico, Peru, Surinam, Taiwan, the Philippines, the U.S.A., Venezuela, etc.

Simple setting of the clock by time difference

When you are abroad, you can easily adjust the clock to the local time by setting the time difference. Select [AREA SET], then set the time difference (p. 86).

File/folder structure on the memory card and the flash memory unit

The file/folder structure is shown below. You do not usually need to acknowledge the file/folder structure, when recording/playing back movies and still images on the camcorder.



- * "Memory Stick PRO Duo" media, flash memory unit
- **SD memory card, SDHC memory card
- 1 Image management files
 When you delete the files, you cannot record/play back the images correctly.
 The files are defaulted as hidden files and not usually displayed.
- 2 HD movie management information folder

This folder contains recording data of high definition image quality (HD) movies. Do not try to open this folder or access the contents of this folder from a computer. Doing so might damage image files, or prevent image files from being played back.

3 SD movie files (MPEG-2 files)
The extension of the files is ".MPG".
The maximum size is 2 GB. When the capacity of a file exceeds 2 GB, the file becomes divided.

The file numbers go up automatically. When the capacity of a file number exceeds 9999, another folder is created to record new movie files. The folder name goes up: [101PNV01] → [102PNV01]

4 Still image files (JPEG files)
The extension of the files is ".JPG". The file numbers go up automatically. When the capacity of a file number exceeds

9999, another folder is created to store new still image files.

The folder name goes up: [101MSDCF] \rightarrow [102MSDCF]

- Do not modify the files or folders on the camcorder from the computer. The image files may be destroyed or may not be played back.
- Operation is not guaranteed, if you perform the above operation.
- When you delete image files, follow the steps on page 62. Do not delete the image files on the camcorder directly from the computer.
- Do not format the recording media using a computer. The camcorder may not operate correctly.
- Do not copy the files on the recording media from the computer. Operation is not guaranteed.
- Use the supplied application software "Content Management Utility" to input data from the recording media to a computer.

Maintenance and precautions

About the AVCHD format

What is the AVCHD format?

The AVCHD format is a high definition digital video camera format used to record a high definition (HD) signal, using efficient data compression coding technology. The MPEG-4 AVC/H.264 format is adopted to compress video data, and the Dolby Digital or Linear PCM system is used to compress audio data.

The MPEG-4 AVC/H.264 format is capable of compressing images at higher efficiency than that of the conventional image compressing format.

· Because the AVCHD format uses a data compression system, images may be distorted in scenes where the image, angle, or brightness changes drastically. This is not a malfunction.

Recording and playback on your camcorder

Based on the AVCHD format, your camcorder records with the high definition image quality (HD). In addition to high definition image quality (HD), your camcorder is capable of recording a standard definition (SD) signal in the conventional MPEG2 format.

Video signal*: MPEG-4 AVC/H.264 1920 ×1080/50i, 1280 ×720/50p, 1440 × 1080/50i

Audio signal: Dolby Digital 2ch, Linear

Recording media: memory card, flash memory unit (sold separately)

- * Data recorded in AVCHD format other than the above mentioned cannot be played back on your camcorder.
- 1080i specification A high definition specification which utilizes 1,080 effective scanning lines and the interlace system.
- 720p specification A high definition specification which utilizes 720 effective scanning lines and the progressive system.

About GPS (HXR-NX5E/NX5P)

The GPS (Global Positioning System) is a system that calculates geographical location from highly accurate US space satellites. The GPS satellites are located in 6 orbits, 20,000 km above the earth. The GPS system consists of 24 or more GPS satellites. A GPS receiver receives radio signals from the satellites, and calculates the current location of the receiver based on the orbital information (almanac data) and travel time of the signals, etc. Determining a location is called "triangulating." A GPS receiver can determine the location's latitude and longitude by receiving signals from 3 or more satellites.

4 Notes

- · As the positions of GPS satellites vary constantly, it may take longer to determine the location or the receiver may not be able to determine the location at all, depending on the location and time you use the camcorder.
- "GPS" is a system for determining geographic location by triangulating radio signals from GPS satellites. Avoid using the camcorder in places where radio signals are blocked or reflected. such as a shadowy place surrounded by buildings or trees, etc. Use the camcorder in open sky environments.
- · You may not be able to record location information at locations or in situations where radio signals from the GPS satellites do not reach the camcorder as follows.
 - In tunnels, indoors or under the shade of buildings.
 - Between tall buildings or at narrow streets surrounded by buildings.
 - In underground locations, locations surrounded by dense trees, under an elevated bridge, or in locations where magnetic fields are generated, such as near high voltage cables
 - Near devices that generate radio signals of the same frequency band as the camcorder: near 1.5 GHz band mobile telephones, etc.

On triangulating errors

- If you move to another location right after setting the GPS switch to ON, it may take a longer time for the camcorder to start triangulating, compared to when you stay in the same place.
- Error caused by the position of GPS satellites

The camcorder automatically triangulates your current location when the camcorder receives radio signals from 3 or more GPS satellites. The triangulating error allowed by the GPS satellites is about 30 m (98 feet). Depending on the environment of the location, the triangulating error can be greater. In this case, your actual location may not match the location on the map based on the GPS information.

Meanwhile, the GPS satellites are controlled by the Unites States

Department of Defense, and the degree of accuracy may be changed intentionally.

 Error during the triangulating process The camcorder acquires location information every second during triangulating.

On the restriction of use of GPS on an airplane

During take off and landing of an airplane, set the GPS switch to OFF and turn off the camcorder, as you will be instructed to do by the on-board announcement. In other cases, use GPS in accordance with the regulations of the place or situation.

On the geographic coordinate system

The "WGS-84" geographic coordinate system is used.

About the "Memory Stick" media

"Memory Stick" media are compact, portable IC recording media with a large data capacity.

You can use only "Memory Stick Duo" media, which are about the half size of standard "Memory Stick" media, with your camcorder.

However, we do not guarantee the operation of all types of "Memory Stick Duo" media on your camcorder.

Types of "Memory Stick" media	Recording /Playback
"Memory Stick Duo" media (with MagicGate)	-
"Memory Stick PRO Duo" media	0
"Memory Stick PRO-HG Duo" media	0*

- * This product does not support 8-bit parallel data transfer but it supports 4-bit parallel data transfer the same as with "Memory Stick PRO Duo" media.
- This product cannot record or play data that uses "MagicGate" technology. "MagicGate" is a copyright protection technology that records and transfers the contents in an encrypted format.
- "Memory Stick PRO Duo" media formatted by a computer (Windows OS/Mac OS) do not have guaranteed compatibility with your camcorder.
- Data read/write speed may vary depending on the combination of the "Memory Stick PRO Duo" media and "Memory Stick PRO Duo" media compliant product you use.
- Damaged or lost image data will not be compensated for, and may occur in the following cases:
- If you eject the "Memory Stick PRO Duo" media, turn the power off on your camcorder, or remove the battery pack for replacement while your camcorder is reading or writing image files on the "Memory Stick PRO Duo" media (while the access lamp is lit or flashing).
- If you use the "Memory Stick PRO Duo" media near magnets or magnetic fields.

- · It is recommended to make a back-up of important data on the hard disk of a computer.
- · Be careful not to apply excessive force when writing on a memo area on "Memory Stick PRO Duo" media.
- · Do not attach a label or the like on "Memory Stick PRO Duo" media or a "Memory Stick Duo" media adaptor.
- · When you carry or store a "Memory Stick PRO Duo" media, put it in its case.
- · Do not touch, or allow metallic objects to come into contact with the terminals.
- · Do not bend, drop or apply strong force to the "Memory Stick PRO Duo" media.
- · Do not disassemble or modify the "Memory Stick PRO Duo" media.
- · Do not let the "Memory Stick PRO Duo" media
- · Be careful to keep "Memory Stick PRO Duo" media out of the reach of small children. There is danger that a child might swallow it.
- · Do not insert anything other than "Memory Stick PRO Duo" media into the "Memory Stick Duo" media slot. Doing so may cause a malfunction.
- · Do not use or keep the "Memory Stick PRO Duo" media in the following locations:
 - Places subject to extremely high temperature, such as a car parked outside in the summer.
 - Places under direct sunlight.
 - Places with extremely high humidity or subject to corrosive gases.

On the "Memory Stick Duo" media adaptor

- · When using a "Memory Stick PRO Duo" media with a "Memory Stick" media compliant device, make sure to insert the "Memory Stick PRO Duo" media into a "Memory Stick Duo" media adaptor.
- · When inserting "Memory Stick PRO Duo" media into a "Memory Stick Duo" media adaptor, make sure the "Memory Stick PRO Duo" media is inserted facing in the correct direction, then insert it all the way in. Note that improper use may cause a malfunction.
- · When using "Memory Stick PRO Duo" media that is inserted into a "Memory Stick Duo" media adaptor with a "Memory Stick" media compliant device, make sure the "Memory Stick PRO Duo" media is inserted into the "Memory Stick" media compliant device facing in the

- correct direction. Note that improper use may damage the device.
- Do not insert "Memory Stick Duo" media adaptor without "Memory Stick PRO Duo" media attached into a "Memory Stick" media compliant device. Doing so may result in malfunctions of the unit.

On image data compatibility

- · Image data files recorded on a "Memory Stick PRO Duo" media by your camcorder conform to the "Design rule for Camera File system" universal standard established by the JEITA (Japan Electronics and Information Technology Industries Association).
- · On your camcorder, you cannot play back still images recorded on other devices (DCR-TRV900E or DSC-D700/D770) that do not conform to the universal standard. (These models are not sold in some regions.)
- · If you cannot use "Memory Stick PRO Duo" media that has been used with another device, format it with your camcorder (p. 65). Note that formatting erases all information on the "Memory Stick PRO Duo" media.
- · You may not be able to play back images with your camcorder:
- When playing back image data modified on your computer.
- When playing back image data recorded with other devices

About the "InfoLITHIUM" battery pack

This unit is compatible with an "InfoLITHIUM" battery pack (L series). Your camcorder operates only with an "InfoLITHIUM" battery pack. "InfoLITHIUM" L series battery packs

What is an "InfoLITHIUM" battery pack?

An "InfoLITHIUM" battery pack is a lithium-ion battery pack that has functions for communicating information related to operating conditions between your camcorder and a supplied AC Adaptor/ Charger.

The "InfoLITHIUM" battery pack calculates the power consumption according to the operating conditions of your camcorder, and displays the remaining battery time in minutes.

With an AC Adaptor/Charger, the remaining battery time and charging time appear.

To charge the battery pack

- Be sure to charge the battery pack before you start using your camcorder.
- We recommend charging the battery pack in an ambient temperature of between 10 °C to 30 °C (50 °F to 86 °F) until the charge lamp of the AC Adaptor/Charger turns off. If you charge the battery pack outside of this temperature range, you may not be able to charge it efficiently.

To use the battery pack effectively

- Battery pack performance decreases when the ambient temperature is 10 °C (50 °F) or below, and the length of time you can use the battery pack becomes shorter. In that case, do one of the following to use the battery pack for a longer time.
 - Put the battery pack in a pocket to warm it up, and insert it in your camcorder right before you start taking shots.
 - Use a large capacity battery pack: NP-F770/ F970 (sold separately).
- Frequent use of the LCD screen or a frequent playback, fast forward or rewind operation wears out the battery pack faster.
 We recommend using a large capacity battery pack: NP-F770/F970 (sold separately).
- Be sure to set the POWER switch to OFF when not recording or playing back on your camcorder. The battery pack is also consumed when your camcorder is in recording standby or playback pause.
- Have spare battery packs ready for two or three times the expected recording time, and make trial recordings before making the actual recording.
- Do not expose the battery pack to water. The battery pack is not water resistant.

About the remaining battery time indicator

- When the power goes off even though the remaining battery time indicator indicates that the battery pack has enough power to operate, charge the battery pack fully again. Remaining battery time will be indicated correctly. Note, however, that the battery indication will not be restored if it is used in high temperatures for a long time, or if left in a fully charged state, or when the battery pack is frequently used. Use the remaining battery time indication as a rough guide only.
- The \(\sigma\) mark that indicates low battery flashes even if there are still 5 to 10 minutes of battery time remaining, depending on the operating conditions or ambient temperature.

About storage of the battery pack

- If the battery pack is not used for a long time, fully charge the battery pack and use it up on your camcorder once a year to maintain proper function. To store the battery pack, remove it from your camcorder and put it in a dry, cool place.
- To discharge the battery pack on your camcorder completely, leave your camcorder in recording standby until the power goes off (p. 14).

About battery life

- Battery capacity decreases over time and through repeated use. If decreased usage time between charges becomes significant, it is probably time to replace it with a new one.
- Each battery's life is governed by storage, operating and environmental conditions.

About charging the battery pack

- Use the AC Adaptor/Charger (supplied) to charge the designated batteries only. If you charge other types of batteries, those batteries may leak, heat up, burst, or give an electric shock, resulting in burns or injury.
- Remove the charged battery from the AC Adaptor/Charger.
- The CHARGE lamp of the supplied AC Adaptor/Charger flashes in 2 patterns as follows:

Fast-flashing...Turns on and off rapidly at about

0.15-second intervals.

Slow-flashing...Turns on and off alternately for about 1.5 seconds, and turns off completely for about 1.5 seconds. The lamp repeats this sequence.

- · If the CHARGE lamp is fast-flashing, remove the battery that is being charged, and then reattach the same battery again firmly. If the CHARGE lamp continues fast-flashing, the cause could be that the battery is damaged, or the battery is not a designated type. Check the battery to confirm whether it is a designated type or not. If it is a designated type, remove the battery first, and then attach a brand-new battery or another known-to-be-good battery to see if the AC Adaptor/Charger is working correctly. If the AC Adaptor/Charger is working correctly, the cause could be that the battery is damaged.
- · If the CHARGE lamp is slow-flashing, the AC Adaptor/Charger is in standby mode and charging is suspended. When the ambient temperature is out of the appropriate temperature range for charging, the AC Adaptor/Charger suspends charging automatically and enters standby mode. When the ambient temperature returns to an appropriate temperature, the AC Adaptor/ Charger restarts charging and the CHARGE lamp lights up. We recommend charging the battery pack in an ambient temperature of between 10 °C to 30 °C (50 °F to 86 °F).

About x.v.Color

- · x.v.Color is a more familiar term for the xvYCC standard proposed by Sony, and is a trademark of Sonv.
- xvYCC is an international standard for color space in video. This standard can express a wider color range than the currently used broadcast standard.

About handling of your camcorder

On use and care

- · Do not use or store the camcorder and accessories in the following locations.
 - Anywhere extremely hot or cold. Never leave them exposed to temperatures above 60 °C (140 °F), such as under direct sunlight, near

- heaters or in a car parked in the sun. They may malfunction or become deformed.
- Near strong magnetic fields or mechanical vibration. The camcorder may malfunction.
- Near strong radio waves or radiation. The camcorder may not be able to record properly.
- Near AM receivers and video equipment. Noise may occur.
- On a sandy beach or anywhere dusty. If sand or dust gets in your camcorder, it may malfunction. Sometimes this malfunction cannot be repaired.
- Near windows or outdoors, where the LCD screen, the viewfinder, or the lens may be exposed to direct sunlight. This damages the inside of the viewfinder or the LCD screen.
- Anywhere very humid.
- Operate your camcorder on DC 7.2 V (battery pack) or DC 8.4 V (AC Adaptor).
- For DC or AC operation, use the accessories recommended in these operating instructions.
- · Do not let your camcorder get wet, for example, from rain or sea water. If your camcorder gets wet, it may malfunction. Sometimes this malfunction cannot be repaired.
- · If any solid object or liquid gets inside the casing, unplug your camcorder and have it checked by a Sony dealer before operating it any further.
- · Avoid rough handling, disassembling, modifying, physical shock, or impact such as hammering, dropping or stepping on the product. Be particularly careful of the lens.
- · Do not use a deformed or damaged battery pack.
- · Keep the POWER switch setting to OFF when you are not using your camcorder.
- · Do not wrap your camcorder with a towel, for example, and operate it. Doing so might cause heat to build up inside.
- When disconnecting the power cord (mains lead), pull it by the plug and not the lead.
- Do not damage the power cord (mains lead) such as by placing anything heavy on it.
- Keep metal contacts clean.
- · Keep the Wireless Remote Commander and button-type battery out of children's reach. If the battery is accidentally swallowed, consult a doctor immediately.
- If the battery electrolytic liquid has leaked.
 - consult your local authorized Sony service facility.

Maintenance and precautions (Continued)

- wash off any liquid that may have contacted your skin.
- if any liquid gets in your eyes, wash with plenty of water and consult a doctor.

■ When not using your camcorder for a long time

- Periodically turn on the camcorder and play back images for about 3 minutes.
- Use up the battery pack completely before storing it.

Moisture condensation

If your camcorder is brought directly from a cold place to a warm place, moisture may condense inside your camcorder and cause a malfunction of your camcorder.

■ If moisture condensation has occurred

Leave your camcorder for about 1 hour without turning it on.

Note on moisture condensation

Moisture may condense when you bring your camcorder from a cold place into a warm place (or vice versa) or when you use your camcorder in a humid place as shown below.

- When you bring your camcorder from a ski slope into a place warmed up by a heating device.
- When you bring your camcorder from an air conditioned car or room into a hot place outside.
- When you use your camcorder after a squall or a shower.
- When you use your camcorder in a hot and humid place.

How to avoid moisture condensation

When you bring your camcorder from a cold place into a warm place, put your camcorder in a plastic bag and seal it tightly. Remove the bag when the air temperature inside the plastic bag has reached the ambient temperature (after about 1 hour).

LCD screen

- Do not exert excessive pressure on the LCD screen, as it may cause damage.
- If your camcorder is used in a cold place, a residual image may appear on the LCD screen. This is not a malfunction.

 While using your camcorder, the back of the LCD screen may heat up. This is not a malfunction.

To clean the LCD screen

If fingerprints or dust make the LCD screen dirty, it is recommended you use a soft cloth to clean it. When you use the LCD Cleaning Kit (sold separately), do not apply the cleaning liquid directly to the LCD screen. Use cleaning paper moistened with the liquid.

On adjustment of the touch panel (CALIBRATION)

The buttons on the touch panel may not work correctly. If this happens, follow the procedure below. It is recommended that you connect your camcorder to the wall outlet (wall socket) using the supplied AC Adaptor/Charger during the operation.

- 1 Turn on the camcorder.



- ③ Touch "x" displayed on the screen with the corner of memory card or the like 3 times.
 - If you did not press the right spot, try the calibration again.
 - · Touch [CANCEL] to cancel calibration.

6 Notes

 Do not use a sharp-pointed object for calibration. Doing so may damage the LCD screen

On handling the casing

- If the casing is soiled, clean the camcorder body with a soft cloth lightly moistened with water, and then wipe the casing with a dry soft cloth.
- Avoid the following to avoid damage to the finish.

- Using chemicals such as thinner, benzine, alcohol, chemical cloths, repellent, insecticide and sunscreen.
- Handling with above substances on your hands.
- Leaving the casing in contact with rubber or vinyl objects for a long period of time.

About care and storage of the lens

- Wipe the surface of the lens clean with a soft cloth in the following instances:
 - When there are fingerprints on the lens surface.
 - In hot or humid locations
 - When the lens is exposed to salty air such as at the seaside.
- Store in a well-ventilated location subject to little dirt or dust.
- To prevent mold, periodically clean the lens as described above. It is recommended that you operate your camcorder about once a month to keep it in optimum state for a long time.

On charging the pre-installed rechargeable battery

Your camcorder has a pre-installed rechargeable battery to retain the date, time, and other settings even when the POWER switch is set to OFF. The pre-installed rechargeable battery is always charged while your camcorder is connected to the wall outlet (wall socket) via the AC Adaptor/Charger or while the battery pack is attached. The rechargeable battery will be fully discharged in about **3 months** if you do not use your camcorder at all without the AC Adaptor/Charger connected or the battery pack attached. Use your camcorder after charging the pre-installed rechargeable battery.

However, even if the pre-installed rechargeable battery is not charged, the camcorder operation will not be affected as long as you are not recording the date.

Procedures

Connect your camcorder to a wall outlet (wall socket) using the supplied AC Adaptor/Charger, and leave it with the

POWER switch set to OFF for more than 24 hours

Removing dust from inside the viewfinder

1 Remove the eye piece of the viewfinder.

Slide down the viewfinder release lever and hold it at the position (①), then lift the eye piece of the viewfinder as indicated with the arrow in the illustration (②).



2 Remove dust inside the eye piece and viewfinder with a blower.



Specifications

System f=4.1 - 82.0 mm (3/16 - 3 1/4 in.) When converted to a 35 mm still Video signal camera* PAL color, CCIR standards 29.5 - 590 mm (1 3/16 - 23 1/4 in.) HDTV 1080/50i, 720/50p (16:9),Video recording system 36.1 - 722 mm (1 7/16 - 28 1/2 in.) HD image quality: MPEG-4 AVC/ (4:3)H.264 AVCHD F16-34 SD image quality: MPEG-2 PS Filter diameter: 72 mm (2 7/8 in.) Audio recording system Color temperature Linear PCM 2ch (48 kHz 16-bit) [AUTO] Dolby Digital 2ch (48 kHz 16-bit) (one push) A/B Dolby Digital Stereo Creator employed [INDOOR] (3 200K) Still image recording system [OUTDOOR] (5 800K±7 offset levels) DCF Ver. 2.0 [MANU WB TEMP] (2 300K -Exif Ver. 2.21 15 000K in 100K steps) MPF Baseline Minimum illumination Recording media (movies/still images) 1.5 lx (lux) (Fixed Shutter Speed 1/25, "Memory Stick PRO Duo" media auto gain, auto iris) (F 1.6) Flash memory units * When [SET] of [STEADYSHOT] is set to SD memory cards, SDHC memory [STEADYSHOT] or [OFF] cards (Class 4, 6, 10) Viewfinder Output connectors Electric viewfinder (color, black and VIDEO OUT jack Picture: 1.1 cm (0.45 type, aspect ratio Pin connector 1 Vp-p, 75 Ω (ohms) unbalanced, sync 16:9) Total dot number: negative **AUDIO OUT jacks** 1 226 880 (approx. 852 × 3 [RGB] × Pin connectors 480) -10 dBu (at load impedance 47 k Ω Image device 6.0 mm (1/3 type) 3CMOS sensor (kilohms)), Output impedance with less Gross: Approx. 1 120 000 pixels than 2.2 k Ω (kilohms) Effective (movie, 16:9): (0 dBu = 0.775 Vrms)Approx. 1 040 000 pixels* COMPONENT OUT jack Effective (movie, 4:3): Mini-D jack Y: 1 Vp-p, 75 Ω (ohms) Approx. 780 000 pixels* PB/PR, CB/CR: 0.7 Vp-p, 75 Ω (ohms) Lens **HDMI OUT jack** G Lens HDMI connector $20 \times (Optical)$, Approx. $30 \times (Digital)$, when [D.EXTENDER] is set to [ON]) SDI OUT jack BNC Focal length

SMPTE292M/259M

(headphones) jack

Stereo-minijack (Ø 3.5 mm)

Input connectors

INPUT1/INPUT2 jacks

XLR 3-pin, female,

MIC: -48 dBu: 3 kΩ (kilohms) (Variable in the range of between -60 dBu and -30 dBu in 6 dBu step by

the INPUT TRIM function) LINE: +4 dBu: $10 \text{ k}\Omega$ (kilohms)

(0 dBu = 0.775 Vrms)

Input/Output connectors

USB jack

mini-B

Remote iack

Stereo mini-minijack (Ø 2.5 mm)

TC LINK IN/OUT jack

Pin connector IN: 0.5 V to 18 Vp-p, $10 \text{ k}\Omega$ (kilohms) OUT: 1.2 Vp-p, 75 Ω (ohms) (IN/OUT switch-able)

LCD screen

Picture

8.0 cm (3.2 type, aspect ratio 16:9)

Total dot number

 $921\ 600\ (1\ 920 \times 480)$

General

Power requirements

DC 7.2 V (battery pack) DC 8.4 V (AC Adaptor/Charger)

Average power consumption* HXR-NX5E/NX5P

During camera recording using the microphone ECM-XM1 and viewfinder with normal brightness:

7.7 W

During camera recording using the microphone ECM-XM1 and LCD with normal brightness:

7.7 W

HXR-NX5M

During camera recording using the microphone ECM-XM1 and viewfinder with normal brightness:

7.4 W

During camera recording using the microphone ECM-XM1 and LCD with normal brightness:

7 4 W

* When Flash Memory Unit HXR-FMU128 is used, the average power consumption increases about 1.1 W.

Operating temperature

0 °C to 40 °C (32 °F to 104 °F)

Storage temperature

 $-20 \,^{\circ}\text{C}$ to $+60 \,^{\circ}\text{C}$ (-4 $^{\circ}\text{F}$ to $+140 \,^{\circ}\text{F}$)

Dimensions (approx.)

 $173 \times 193 \times 449 \text{ mm}$

 $(6.7/8 \times 7.5/8 \times 17.3/4 \text{ in.}) (\text{w/h/d})$ including the projecting parts 173 × 193 × 449 mm $(6.7/8 \times 7.5/8 \times 17.3/4 \text{ in.}) (\text{w/h/d})$ including the projecting parts with the

battery pack (NP-F570)

Mass (approx.)

2.2 kg (4 lb 15 oz) including the lens hood with lens cover 2.5 kg (5 lb 7 oz) including the battery

pack (NP-F570), lens hood with lens cover and microphone (ECM-XM1)

AC Adaptor/Charger AC-VL1

Power requirements

AC 100 V - 240 V, 50 Hz/60 Hz

Power consumption

22 W

Output voltage

DC 8.4 V*

Specifications (Continued)

Operating temperature

0 °C to 40 °C (32 °F to 104 °F)

Storage temperature

-20 °C to +60 °C (-4 °F to +140 °F)

Dimensions (approx.)

 $136 \times 51 \times 90$ mm (5 $3/8 \times 2$ $1/8 \times 3$ 5/8 in.) (w/h/d) excluding the projecting parts

Mass (approx.)

270 g (9.6 oz) excluding the power cord (mains lead)

* See the label on the AC Adaptor/Charger for other specifications.

Rechargeable battery pack NP-F570

Maximum output voltage

DC 8.4 V

Output voltage

DC 7.2 V

Maximum charge voltage

DC 8.4 V

Maximum charge current

3.0 A

Capacity

Typical: 15.8 Wh (2 200 mAh) Minimum: 15.0 Wh (2 100 mAh)

Type

Li-ion

Design and specifications are subject to change without notice.

 Manufactured under license from Dolby Laboratories

On trademarks

- "NXCAM" logo is a trademark of Sony Corporation.
- "AVCHD" and "AVCHD" logotype are trademarks of Panasonic Corporation and Sony Corporation.
- "Memory Stick," "Memory Stick Duo," "Memory Stick Duo," "MEMORY STICK DUO," "MEMORY STICK PRO DUO," "MEMORY STICK PRO DUO," "MEMORY STICK PRO DUO,"

 "Memory Stick PRO-HG Duo,"
 - "MEMORY STICK PRO-HG Dup." "MagicGate,"
 "MAGICGATE," "MagicGate Memory
 Stick" and "MagicGate Memory Stick Duo" are
 trademarks of Sony Corporation.
- "InfoLITHIUM" is a trademark of Sony Corporation.
- is a trademark of Sony Corporation.
- "x.v.Colour" is a trademark of Sony Corporation.
- Dolby and the double-D symbol are trademarks of Dolby Laboratories.
- Microsoft, Windows, and Windows Vista are trademarks or registered trademarks of U.S. Microsoft Corporation in the U.S. and other countries.
- Macintosh and Mac OS are registered trademarks of Apple Inc. in the U.S. and other countries.
- HDMI, HDMI logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.
- Intel, Intel Core, and Pentium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.
- Adobe, the Adobe logo, and Adobe Acrobat are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.
- · SDHC logo is a trademark.



 MultiMedia Card is a trademark of MultiMediaCard Association.

All other product names mentioned herein may be the trademarks or registered trademarks of their respective companies. Furthermore, TM and "®" are not mentioned in each case in this manual.

Notes on the License

ANY USE OF THIS PRODUCT OTHER THAN CONSUMER PERSONAL USE IN ANY MANNER THAT COMPLIES WITH THE MPEG-2 STANDARD FOR ENCODING VIDEO INFORMATION FOR PACKAGED MEDIA IS EXPRESSLY PROHIBITED WITHOUT A LICENSE UNDER APPLICABLE PATENTS IN THE MPEG-2 PATENT PORTFOLIO, WHICH LICENSE IS AVAILABLE FROM MPEG LA, L.L.C., 250 STEELE STREET, SUITE 300, DENVER, COLORADO 80206.

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO

- (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND /OR
- (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND

NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO.

NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE.
ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C.
SEE <http://mpegla.com>

"C Library," "Expat," "zlib," "libjpeg," "dtoa" and "pcre" software are provided in your camcorder. We provide this software based on license agreements with their owners of copyright. Based on requests

by the owners of copyright of these software applications, we have an obligation to inform you of the following. Please read the following sections.

Read "licensel.pdf" in the "License" folder on the CD-ROM "Content Management Utility." You will find licenses (in English) of "C Library," "Expat," "zlib," "libjpeg," "dtoa" and "pcre" software.

On GNU GPL/LGPL applied software

The software that is eligible for the following GNU General Public License (hereinafter referred to as "GPL") or GNU Lesser General Public License (hereinafter referred to as "LGPL") are included in the camcorder.

This informs you that you have a right to have access to, modify, and redistribute source code for these software programs under the conditions of the supplied GPL/LGPL.

Source code is provided on the web. Use the following URL to download it. When downloading the source code, select HXR-NX5J as the model for your camcorder.

http://www.sony.net/Products/Linux/

We would prefer you do not contact us about the contents of source code.


Read "license2.pdf" in the "License" folder on the CD-ROM "Content Management Utility." You will find licenses (in English) of "GPL," and "LGPL," software.

To view the PDF, Adobe Reader is needed. If it is not installed on your computer, you can download it from the Adobe Systems web page:

http://www.adobe.com/

Identifying parts and controls

The numbers in () are reference pages.




- 1 Hook for shoulder strap (119)
- 2 ASSIGN 7/EXPANDED FOCUS button (45)
- 3 Accessory shoe mount
- 4 Microphone fixing clamper (10)
- **5** Microphone holder (10)

- **6** Microphone (10)
- 7 Accessory shoe
- 8 TC LINK switch (43)
- 9 TC LINK IN/OUT jack (43)
- **10** Zoom lever (26)


To mount the accessory shoe

Mount the accessory shoe on the accessory shoe mount as illustrated.

Accessory shoe plate



Accessory shoe




Accessory shoe plate

① Lift the edge of the accessory shoe plate and pull it in the direction opposite to that of the arrow on the accessory shoe

- plate and remove it from the accessory shoe.
- ② Place the accessory shoe as its protrusions matches recesses of the accessory shoe mount, then fix it to the mount with four screws.
- ③ Insert the accessory shoe plate in the direction of the arrow on the plate surface until the end of the plate engages the end of the shoe.

To remove the accessory shoe


Remove the shoe plate in the same way as step ① of "To mount the accessory shoe." Loosen the 4 screws and remove the accessory shoe from the accessory shoe mount.



- **1** Lens (10)
- 2 Lens hood with lens cover (10)
- 3 Internal microphone (39)
- 4 Front recording lamp (86) The recording lamp flashes if the remaining capacity of recording media or battery is low.
- **5** Remote sensor (87)
- 6 ASSIGN 4/ZEBRA button (45)
- 7 ASSIGN 5/AE SHIFT button* (45)
- 8 ASSIGN 6/VISUAL INDEX button (45)
- 9 CH1 (INT MIC/INPUT1) switch (39)
- 10 AUTO/MAN (CH1) switch (40)
- 11 AUDIO LEVEL(CH1) dial (40)
- 12 AUDIO LEVEL(CH2) dial (40)
- 13 AUTO/MAN (CH2) switch (40)
- 14 CH2 (INT MIC/INPUT1/INPUT2) switch (39)
- 15 ASSIGN 1/2*/3 buttons (45)
- 16 PUSH AUTO button (27)
- 17 FOCUS switch (27)
- 18 ND filter (30)

* The ASSIGN 5/AE SHIFT button and the ASSIGN 2 button have raised tactile dots for your convenience in locating the button.


Identifying parts and controls (Continued)



- 1 VIDEO OUT jack/AUDIO OUT jacks (54)
- 2 COMPONENT OUT jack (54)
- 3 HDMI OUT jack (54)
- **4 \$\psi\$USB** jack (88)
- 5 SDI OUT jack (54)
- 6 RELEASE lever (20)
- 7 Handle zoom lever (26)
- 8 Handle record button (21)
- **9** INPUT2 jack (10)
- **10** INPUT1 jack (10)
- 11 Cable holder (10)
 Provided for securing a microphone cable, etc.
- **12** INPUT2 switch (39)
- **13** INPUT1 switch (39)
- 14 REMOTE jack
 The REMOTE jack is used for controlling playback, etc. on the video device and peripherals connected to it.
- 15 Grip belt (14)
- 16 POWER switch (14)
- 17 Record button (21)


[18] Flash memory unit mount (20) For attaching a flash memory unit (sold separately).

Flash memory unit jack



Flash memory unit jack cover


(19) GPS switch (41) (HXR-NX5E/NX5P) When it is set to ON, the camcorder acquires the GPS information (location and time of recording) and records with images.




- 1 Hook for shoulder strap
- 2 Focus ring (27)
- 3 Lens cover lever (10)
- **4** Zoom ring (26)
- **5** Iris ring (28)
- 6 GAIN button (29)
- 7 WHT BAL button* (30)
- 8 SHUTTER SPEED button (29)
- 9 AUTO/MANUAL switch (28)
- (headphones) jack For stereo mini-jack headphones
- 11 BATT RELEASE button (12)
- 12 Battery pack (12)
- Memory card B slot/select button/access lamp (19)
- Memory card A slot/select button/ access lamp (19)
- **15 №** (One push) button (31)
- 16 White balance memory switch (30)
- 17 Gain switch (29)
- **18** IRIS button (28)
- * WHT BAL button has a raised tactile dot for your convenience in locating the button.

To attach a shoulder strap

Attach a shoulder strap (sold separately) to the hooks for a shoulder strap.



Identifying parts and controls (Continued)




- 1 RESET button
 If you press the RESET button, all settings including the clock setting (except the picture profile settings) return to the default.
- 2 VISUAL INDEX button (47)
- 3 Playback control buttons (PREV/ PLAY*/NEXT/STOP/PAUSE/SCAN/ SLOW) (47)
- 4 DATA CODE button (51)
- 5 DISPLAY button (51)
- 6 LCD screen/touch panel (15)
- 7 Handle zoom switch (26)
- 8 Viewfinder (16)
- 9 Large eyecup (16)
- 10 Viewfinder lens adjustment lever (16)
- 11 Viewfinder release lever (111)
- 12 HEADPHONE MONITOR switch (41)
- [13] Rear recording lamp (86)

 The recording lamp flashes if the remaining capacity of recording media or battery is low.
- 14 STATUS CHECK button (52)
- 15 PICTURE PROFILE button* (32)
- 16 MODE button (57)

- 17 MENU button** (17, 67)
- [18] SEL/PUSH EXEC dial/◆/→ buttons (17, 67)
- 19 VOLUME buttons* (47)
- 20 TC/U-BIT button Switches between time code and user bit to display on the LCD screen.
- 21 MODE button (57)
- **22 ♦/♦/♦/EXEC** buttons (67)
- 23 MENU button* (17, 67)
- * PICTURE PROFILE button, VOLUME+ button, MENU button, and PLAY button have raised tactile dots for your convenience in locating the buttons.
- **MENU button has a raised tactile bar for your convenience in locating the button.

Wireless Remote Commander

Remove the insulation sheet before using the Wireless Remote Commander.



- 1 DATA CODE button (51)
- 2 TC RESET button (43)
- 3 SCAN/SLOW buttons (47)
- 4 PREV/NEXT) buttons (47)
- 5 PLAY button (47)
- **6** STOP button (47)
- 7 DISPLAY button (51)
- 8 Transmitter
- 9 START/STOP button (21)
- 10 Power zoom buttons (26)
- 11 PAUSE button (47)
- **12** MODE button (57)
- 13 **◄/►/▲/▼/ENTER** buttons

Notes

 Aim the Wireless Remote Commander towards the remote sensor to operate your camcorder.

- Point the remote sensor away from strong light sources such as direct sunlight or overhead lighting. Otherwise, the Wireless Remote Commander may not function properly.
- When you are operating with the Wireless Remote Commander supplied with your camcorder, your video device may also operate. In that case, select a commander mode other than DVD2 for your video device, or cover the sensor of your video device with black paper.

To change the battery of the Wireless Remote Commander

- ① While pressing on the tab, inset your fingernail into the slit to pull out the battery case.
- ② Place a new battery with the + side facing up.
- ③ Insert the battery case back into the Wireless Remote Commander until it clicks.




WARNING

Battery may explode if mistreated. Do not recharge, disassemble or dispose of in fire.

 When the lithium battery becomes weak, the operating distance of the Wireless Remote Commander may shorten, or the Wireless Remote Commander may not function properly. In this case, replace the battery with a Sony CR2025 lithium battery. Use of another battery may present a risk of fire or explosion.

Screen indicators



Upper left

Indicator	Meaning
	Remaining battery
HD 1080/50i <u>F</u> X	FORMAT (25)
4:3	SDI WIDE REC (77)
** * <u>*</u> * ₁₁	GPS triangulating status (41)
NDOFF ND1 ND2 ND3	ND filter (30)

Center

Indicator	Meaning
€A €B ŒXT	Recording media
•A → •B •B → •A	Relay recording (22)
STBY REC	Recording status (21)
$rac{1}{2}$	Warning (99)
	Playback indicator (47)

Upper right

Indicator	Meaning
0min	Estimated remaining recording time
€A €B ŒXT	Recording/playback media
00:00:00:00	Time code (hour:minute:second: frame)
TC IN	Time code input (44)

Indicator	Meaning
FOFF	LCD backlight off (15)
WHITE FADER BLACK FADER	Fader (75)

Bottom

Indicator	Meaning
PEAKING	PEAKING (81)
88	ZEBRA (81)
ACT OFF	STEADYSHOT (73)
DIG.EXT	D.EXTENDER (75)
(COLOR)	x.v.Color (75)
€ ∆ .	Manual focus (27)
™ OFF	FOCUS MACRO (74)
PP1 ~ PP6	Picture profile (32)
∂ ₂	BACK LIGHT (73)
	SPOTLIGHT(73)
HYPER	HYPER GAIN (71)
CLOSE	Iris (28)
9dB	Gain (29)
50	Shutter speed (29)
♪ M2]	Manual volume control
	(40)
♪LPCM ♪DolbyD	HD: AUDIO FORMAT (78)
AS	AE SHIFT (72)
Δ	Auto setting (82)
* Å ►A B	White balance (30)
114	

🍟 Tips

- Indicators may look different or appear at different positions.
- Some indicators may not appear, depending on your camcorder model.

Data code during recording

The recording date, time and condition are recorded automatically on the recording media. They are not displayed while recording. However, you can check them by pressing the DATA CODE button (p. 51).

Index

Α	C	Expanded focus28
AC Adaptor/Charger12	CALIBRATION 110	EXPANDED FOCUS TYPE
Access lamp19	CAMERA DATA DISPLAY	82
Accessory shoe116	82, 94	EXPANDED FOCUS/ASSIGN 7 button45
Accessory shoe mount116	CAMERA SET menu 71	/ button45
Accessory shoe plate116	CENTER 81	F
ACTIVE STEADYSHOT73	CH1 (INT MIC/INPUT1)	FADER75, 94
AE RESPONSE73	switch39	
AE SHIFT72, 94	CH2 (INT MIC/INPUT1/	Flash memory unit
AE SHIFT/ASSIGN 5 button	INPUT2) switch	Flash memory unit jack20
45	Channel setting	FLICKER REDUCE73
AF ASSIST74	Charge lamp 12	Focus
AGC LIMIT71	Charging time	FOCUS DISPLAY83
AREA SET86, 94	CLOCK SET17	Focus infinity28
ASPECT81	COLOR BAR 76, 94	FOCUS MACRO74
ASSIGN BUTTON45	COLOR DEPTH 36	Focus ring27
ASSIGN buttons45	COLOR LEVEL 35	FOCUS switch27
ATW SENS72	COLOR MODE 35	FREE RUN85
AUDIO LEVEL DISPLAY	COLOR PHASE 35	0
82	Connect	G
AUDIO LEVEL (CH1/CH2)	Computer 88	Gain29
dial40	TV54	GAIN button29
AUDIO LIMIT78	Connecting cord13	GAIN SET71
AUDIO MANUAL GAIN79	COPY38	Gain switch29
AUDIO SET menu78		GAMMA34
AUTO IRIS LIMIT73	D	GPS41
AUTO/MAN (CH1/CH2)	DATA CODE button 51	GPS TIME DISPLAY84
switch40	Date and time 18, 123	Grip belt15
AUTO/MANUAL switch28	DATE REC 86, 94	GUIDEFRAME82
_	DELETE 62	
В	DETAIL 37	Н
BACK LIGHT73, 94	DISPLAY button 15, 51	Handle record button21, 23
BATT RELEASE (battery	DISPLAY OUTPUT 84	HANDLE ZOOM74
release) button12	DISPLAY SET menu 81	Handle zoom26
Battery12	DIVIDE61	Handle zoom lever26
Battery Info52	DOWN CONVERT TYPE	Handle zoom switch26
BEEP86	77	HD AUDIO FORMAT78
BLACK FADER75	D.EXTENDER 75, 94	HD/SD SET24
BLACK GAMMA34		HEADPHONE OUT78
BLACK LEVEL34	E	Headphones jack119
Button-type lithium battery	EXPANDED FOCUS 28	Holding the camcorder15
121		110101115 the cumeorder 13

Hook for shoulder strap119 HYPER GAIN71	Lens	O One push button31 OPERATION TIME87
Image database file	MANAGE MEDIA	OTHERS menu
INPUT1 switch 39 INPUT1 TRIM 79 INPUT1 WIND 79 INPUT2 39 INPUT2 jack 10 INPUT2 switch 39 INPUT2 TRIM 80	Insert/Eject	PEAKING
INPU12 IRIM 80 INPUT2 WIND 80 Insulation sheet 121 INT MIC SENS 79 INT MIC SET 79 INT MIC WIND 79 Internal microphone 79	media	Playback
IRIS	REC/OUT SET menu77 TC/UB SET menu	PROTECT
L LANGUAGE	MODE button	REC BUTTON SET 23 REC CH SELECT switch 39 REC FORMAT 25 REC LAMP[F] 86 REC LAMP[R] 85 REC RUN 85 REC SET 77 Record button 21, 23 Recording 21 Recording format 25

Index (Continued)

Recording image quality24
Recording lamp21
REC/OUT SET menu77
Relay recording22
REMAINING84
REMOTE CONTROL87
Remote sensor117
REPAIR IMAGE DB FILE
66
RESET38, 43
RESET button120
c
S
SAFETY ZONE81
Screen indicators122
SD WIDE REC77
SDI/HDMI/COMPONENT
77
SD-SDI SET78
Self-diagnosis display99
SEL/PUSH EXEC dial 17, 67
Shoulder strap119
SHUTTER DISPLAY83
Shutter speed29
SHUTTER SPEED button
29
Simultaneous recording23
SKINTONE DETAIL38
SMOOTH GAIN71
SMOOTH SLOW REC42
SMOOTH WB72
Specifications112
SPEED ZOOM74
SPOTLIGHT73, 94
Status check52
STATUS CHECK button52
STEADYSHOT73
Still image60
SUMMERTIME86, 94

1
TC MAKE 85
TC PRESET 43, 94
TC RUN85
TC/UB SET menu85
TC/U-BIT button 120
Telephoto
TONE76
Trademark 114
Transmitter121
Triangulating information 41
Troubleshooting90
TV 54
TV color systems 103
U
•
UB PRESET 43
UB TIME REC 85, 94
USB SELECT89
Using the menu 57, 67
Using your camcorder abroad103
UTC TIME 84
01C 11WL04
V
VF BACKLIGHT 83, 94
VF COLOR 84
VF POWERMODE 84
VIDEO OUT77
Viewfinder 16
Viewfinder lens adjustment
lever 16
Viewfinder release lever 111
VISUAL INDEX button 47
VISUAL INDEX/ASSIGN 6
button45
Volume
VOLUME buttons49
W

Warning indicators......99

Warning messages1	00
WB OUTDOOR LEVEL	.72
WB PRESET	.72
WB SHIFT	
WB TEMP SET	.72
White balance	
White balance memory swite	h .31
WHITE FADER	.75
WHT BAL button	
Wide angle	.26
Wireless Remote Commande	
1	21
X	
XLR AGC LINK	.79
XLR SET	.79
x.v.Color75,	94
Z	
ZEBRA81,	94
ZEBRA/ASSIGN 4 button	45
Zoom	.26
ZOOM DISPLAY	.82
Zoom lever	.26
Zoom ring	.26
ZOOM switch	26

http://www.sony.net/ Printed on 70% or more recycled paper using VOC (Volatile Organic Compound)-free vegetable oil based ink.

Printed in Japan

