Laserworld Showeditor

professional laser show software

Quick Start Guide

1. Configure ShowNET Interface:

Dip Switch setting at the interface for AutoIP:

switch	1	2	3	4	5	6	7	8	9	10
On (1) / Off (0)	0	0	0	0	0	1	0	0	0	0

Unplug power supply and reconnect it after having set the Dip switches

2. Download the latest Laserworld Showeditor Software version:

Go to http://www.showeditor.com and download the latest version of Laserworld Showeditor.
The Software version on the CD that comes with this package is only meant as fall-back option. The very latest version can always be found on the website and it's highly recommended to use that one.

3. Install the Laserworld Showeditor Software:

Follow the instructions of the Installer for the Laserworld Showeditor Software Installation.

4. Start Laserworld Showeditor with a click on the Desktop icon

If any error shows up, please refer to our FAQ section at
http://www.showeditor.com/faq

5. Select the operation mode - Live, Timeline, Figure Editor, etc.

Any option is available later as well, as all software parts are completely integrated and linked. Go to *Options -> Hardware* and make sure the ShowNET interface is properly connected. Assign it to track one.

Live Show Window:
Already comes with a large set of preset Figures - give it a try and instantly start with your laser show
Timeline Window:
Especially designed for advanced timeline laser show programming. There are several shows included in delivery - load them and instantly get going
Figure Editor:
Allows for easy figure creation - just draw any shapes or type a text and directly output it to your laser

Read the user manual for more details or if you face any problems.
The user manual can also be found online on

http://www.showeditor.com

Laserworld Showeditor establishes a connection to the Internet during the setup process to load the latest status info for the software.

Imprint:Laserworld (Switzerland) AG | Kreuzlingerstrasse 5 | 8574 Lengwil / Switzerland | phone: +41 71/67780-80 | fax: +41 71/67780-88 | mail: info@laserworld.com
Company Nr. CH-440.3.020.548-6 | CEO: Martin Werner | VAT. Nr. CH: 683 180 | UID: CHE-113.954.889 | EU VAT ID: DE 258 030 001 | WEEE-Reg.-Nr.: DE 90759352